



SCOTTISH HOSPITALS INQUIRY

**Bundle of documents for Oral hearings
commencing from 13 May 2025 in relation
to the Queen Elizabeth University Hospital
and the Royal Hospital for Children,
Glasgow**

**Bundle 47 – Volume 8
Critical Care – Drawings and Room Data
Sheets**

This document may contain Protected Material within the terms of [Restriction Order 1](#) made by the Chair of the Scottish Hospitals Inquiry and dated 26 August 2021. Anyone in receipt of this document should familiarise themselves with the terms of that Restriction Order as regards the use that may be made of this material.

The terms of that restriction order are published on the Inquiry website.

Table of Contents

1	A52352293	Critical Care - 1:200 overall General Arrangement (GA) Plan	Page 4
2	A52396656	Level 1 - 1:300 Reflected Ceiling Plan	Page 5
3	A52569736	Critical Care - 1:50 Reflected Ceiling Plan 1/5	Page 6
4	A52570039	Critical Care - 1:50 Reflected Ceiling Plan 2/5	Page 7
5	A52570050	Critical Care - 1:50 Reflected Ceiling Plan 3/5	Page 8
6	A52570038	Critical Care - 1:50 Reflected Ceiling Plan 4/5	Page 9
7	A52570033	Critical Care - 1:50 Reflected Ceiling Plan 5/5	Page 10
8	A35808732	Critical Care - Patient bedroom and ensuite: Ventilation Layout (PR21) AHU 01	Page 11
9	A33018183	Critical Care - Patient bedroom and ensuite: 1:100 Ventilation Layout	Page 12
10	A35808032	Critical Care - Isolation Room with lobby and ensuite: 1:50 bedroom layout (without elevations) 'type 1'	Page 13
11	A35808030	Critical Care - Isolation Room with lobby and ensuite: 1:50 lobby to isolation room layout (without elevations)	Page 14
12	A35809031	Critical Care - Isolation Room with lobby and ensuite: Ventilation schematic - Typical Isolation Room Rev 02	Page 15
13	A48032049	Critical Care - Isolation Room with lobby and ensuite: Ventilation schematic - Typical Isolation Room Rev 5/B	Page 16
14	A51667962	Critical Care - Room Data Sheets	Page 17
14.1		A51667962 - Excerpt 1 - Contents - Pages 2 - 12	Page 18

14.2	A51667962 - Excerpt 2 - Utility/clinical - Pages 67 - 68	Page 29
14.3	A51667962 - Excerpt 3 - Teaching and Resource office pages - Pages 86 - 88	Page 31
14.4	A51667962 - Excerpt 4 - Critical care bed area, single room; isolation - Pages 97 - 100	Page 34
14.5	A51667962 - Excerpt 5 - Patients ensuite wc & wash double assist - Pages 101 - 104	Page 38
14.6	A51667962 - Excerpt 6 - Gowning lobby; single bedroom - Pages 105 - 107	Page 42
14.7	A51667962 - Excerpt 7 - Single room /Equivalent bed space - Pages 123 - 127	Page 45
14.8	A51667962 - Excerpt 8 - Single room /Equivalent bed space - Pages 128 - 132	Page 50
14.9	A51667962 - Excerpt 9 - Gowning lobby: single bedroom - Pages 183 - 185	Page 55
14.10	A51667962 - Excerpt 10 - Patients ensuite wc & wash double assist - Pages 186 - 189	Page 58
14.11	A51667962 - Excerpt 11 - Critical care bed area, single room; isolation - Pages 190 - 195	Page 62





NOTE : ALL TYPE G TO
BE REPLACED WITH
TYPE F

drawing is copyright. not scale dimensions from this drawing. Discrepancies on this drawing are to be reported to the architect. not modify any element of this drawing. drawing only for purpose(s) issued.	
Identification of Hazard/Risk	
TYPE YOUR NOTES HERE	
CEILING TYPE KEY	
	PLASTERBOARD CEILING - SMOOTH, IMPERFORATE AND JOINTLESS MEMBRANE WITH CONCEALED GRID SYSTEM, NORMAL HUMIDITY AND CLASS 1 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 1)
	600x600mm MOISTURE RESISTANT MINERAL FIBRE TILES - IMPERFORATE AND JOINTED MEMBRANE WITH CONCEALED GRID SYSTEM, HIGH HUMIDITY AND CLASS 1 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 2)
	600x600mm MINERAL FIBRE TILES - IMPERFORATE AND JOINTED MEMBRANE WITH CONCEALED GRID SYSTEM, NORMAL HUMIDITY AND CLASS 1 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 3 & 5)
	600x600mm MINERAL FIBRE TILES - IMPERFORATE AND JOINTED MEMBRANE WITH EXPOSED GRID SYSTEM, NORMAL HUMIDITY AND CLASS 0 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 4)
	800x600mm MINERAL FIBRE TILES - JOINTED MEMBRANE WITH EXPOSED GRID SYSTEM, NORMAL HUMIDITY AND CLASS 1 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 4 & 6)
	600x1200mm SUSPENDED MINERAL TILE PLANK SYSTEM WITH PERIMETER/SIDE PLASTERBOARD MARGIN DETAIL - IMPERFORATE AND JOINTED MEMBRANE WITH EXPOSED GRID SYSTEM, NORMAL HUMIDITY AND CLASS 0 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 4)
	300x1200mm SUSPENDED MINERAL TILE PLANK WITH PERIMETER/SIDE PLASTERBOARD MARGIN DETAIL - IMPERFORATE AND JOINTED MEMBRANE WITH EXPOSED GRID SYSTEM, NORMAL HUMIDITY AND CLASS 0 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 4)
	SUSPENDED FABRIC STRETCH CEILING SYSTEM WITH BACKLIGHTING. SMOOTH, IMPERFORATE AND JOINTLESS MEMBRANE CONCEALED SUPPORT SYSTEM, NORMAL HUMIDITY AND CLASS 1 SURFACE SPREAD OF FLAME (SHTM 60 CATEGORY 1)
	TIMBER SHEATHING WITH ACOUSTIC PROPERTIES AS PER ACOUSTIC CONSULTANTS RECOMMENDATIONS (e.g. WITH PERFORATIONS & CONCEALED ACOUSTIC INSULATION)
	SPECIAL 600x600mm ACOUSTIC TILE. SPECIFICATION TO BE IN LINE WITH THE ACOUSTIC BOOTH DESIGN & AS PER ACOUSTIC CONSULTANTS RECOMMENDATIONS
	X TYPICALLY NO CEILING FINISH REQUIRED BUT ALLOW FOR DUSTPROOF SEALANT, APPLIES TO SOFFITS OF ALL VOIDS, RISERS & M&E CUPBOARDS & PLANT AREAS - UNLESS SPECIFIED SEPARATELY BY THE M&E ENGINEER
	LARGE MODULE METAL CEILING PANEL SYSTEM WITH CONCEALED GRID SETOUT IN WAVE FORMATION WITHIN NSGH ENTRANCE SPACE IN LINE WITH EXTERNAL CANOPY SOFFIT DESIGN (Size approximately 2400x300mm)
	SMALL MODULE METAL CEILING PANEL SYSTEM WITH CONCEALED GRID (Size approximately 1200x600mm)
	SP SPECIAL CEILING FINISH BY SPECIALISTS (TO ADVISE)
	LOCKABLE METAL ACCESS CEILING PANELS WITHIN FINISH PLASTERBOARD CEILING
CEILING FINISHES & HEIGHT DETAILS KEY	
	'BLANK' = FACTORY SELF-FINISH - ALL TILES AND TILE PLANKS
	A ASEPTIC PAINT FINISH / ELASTOMERIC HYGIENE COATING WITH ANTI BACTERIAL PROPERTIES
	P1 WATER BASED ACRYLIC DIAMOND EGGSHELL EMULSION PAINT
	P2 WATER BASED ACRYLIC DIAMOND EGGSHELL EMULSION PAINT WITH ANTI-BACTERIAL PROPERTIES
	BULKHEAD DETAIL - ALL BULKHEADS TYPICALLY MEASURE 300mm BELOW THE ADJACENT CEILING HEIGHT
	CEILING HEIGHT IN METRES (FROM FFL TO UNDERSIDE OF CEILING SOFFIT)
	NOTE: ALL CEILING HEIGHTS ARE +2.7m UNLESS OTHERWISE STATED OR NOTED ON THE DRAWINGS

01/12	CQ	Updated to pre RDD meeting comments	LE	EW		
09/11	CQ	Updated to App K comments (clouded for clarity). Background updated to reflect 1:50 UGM Sign-Off.	EW	EW		
09/10	CQ	Issued for Appendix K (FBC)	AB	AB		
07/10	CQ	FIRST ISSUE	AB	AB		
ate	Drw	Revision Notes	Chk	App		
NEW SOUTH GLASGOW HOSPITALS						
ILE		ACTION				
REF		BY				
- 3 MAR 2012						
ACTION						
COPY TO						




GHTINGALE
associates ■ ■ ■ ■ ■
ewman Street
Y
0207 079 9900
0207 079 9901
htingaleassociates.com


SOUTH GLASGOW HOSPITALS
(H) PROJECT


Title
FLOOR PLAN
FINISHES
STRATEGY PLAN


	Drawn —	Checked EW	Approved EW
		Date _____	Scale @ A.D. _____


Development		15/07/10	1:300
No			Rev
Zone	Level	Type	Content Sequential
XX	01	PL	332 150












Notes:
 • This drawing is copyright.
 • Do not scale dimensions from this drawing.
 • All descriptions on this drawing are to be reported to the architect.
 • All symbols and text are to be read clockwise.
 • Use drawing only for purpose(s) issued.


No

Design Risk Register

NOTES

1. FOR SYMBOLS REFER TO ZBP DRG No.ZBP-XX-XX-DT-590-001
2. THIS DRAWING TO BE READ IN CONJUNCTION WITH ALL CONTRACT DOCUMENTATION





GRILLE DUCT CONNECTIONS SCHEDULE	
DUCT SIZE mm	MAX AIR VOL l/s
100Ø	18
125Ø	28
160Ø	47
200Ø	76
250Ø	125
315Ø	195
355Ø	230

ng is copyright.
ale dimensions from this drawing.
nancies on this drawing are to be reported to the architect.
dify any element of this drawing.
ng only for purpose(s) issued

g corresponds with Architects and Structural Drawings

om the following reference files:
-PL-251-WIP-FirstFloorPlan_02 dated 30/07/10
-PL-252-WIP-FirstFloorPlan_02 dated 30/07/10

al Engineers drawing:
01-PL-260-WIP-STRUCTURAL dated 25/08/10
XX-PL-260-WIP-CRIB dated 25/08/10

- YMBOLS REFER TO
RG No. ZBP-XX-XX-DT-590-001

DRAWING TO BE READ IN CONJUNCTION
ALL CONTRACT DOCUMENTATION

R TO LATEST ARCHITECTURAL AND
CTURAL DRAWINGS AND RELEVANT
STRUCTION DETAILS.

E POSITIONS SHOWN ON THIS DRAWING
IDICATIVE ONLY AND SUBJECT TO FINAL
CTION AND CO-ORDINATION BY CONTRACTOR

E LONG RUNS OF PARALLEL DUCTWORK
A CLEARANCE OF 300mm MUST BE ALLOWED
LOW FOR FIXINGS TO BE MADE TO THE
UTURE FOR PARTITIONING, CEILINGS AND
R SERVICES ETC.

E FIRE RATED DUCTWORK IS INDICATED, IT
EXTEND TO A MINIMUM OF 150mm BEYOND
WALLS OF THE PROTECTED ROOM(S).

E DUCTWORK PASSES THROUGH FIRE OR SOUND
WALLS OR STRUCTURE THE HOLE THROUGH
THE DUCT PASSES SHALL BE MADE GOOD TO
THE RATING OF THE WALL/STRUCTURE

SS PANELS TO BE SIZED AND POSITIONED
CORDANCE WITH HVCA DW/144 & TR19

INDIVIDUAL GRILLE/ DIFFUSER BRANCH DUCT
ECTION SHALL INCORPORATE AN OPPOSED
VOLUME CONTROL DAMPER POSITIONED
AS POSSIBLE FROM THE TERMINAL.
E THIS IS NOT PRACTICAL THE GRILLE/
SER SHALL INCORPORATE AN OPPOSED
VOLUME CONTROL DAMPER.
LARITY THESE DAMPERS ARE NOT
ATED ON THE DRAWINGS

BLE CONNECTIONS SHALL BE UTILISED ON
WORK WHERE DUCTWORK CROSSES
NG MOVEMENT JOINTS

UPDATED TO SUIT REVISED ARCHITECTS LAYOUT	RTS	
UPDATED TO LATEST ARCHITECTURE. MINOR AMENDMENTS TO ISOLATION ROOMS.	RVS	AP
ISSUED FOR INFORMATION	RTS	AP

NSGH Project Business Case) FBC APPENDIX K		
	BROOKFIELD	NSGH BOARD
e:	D. Peters	P. Mar
	1/12/10	23.11.10
	[REDACTED]	[REDACTED]
S: P:	R	X

ER TO CAPITA REPORT
ED 29/10/15

[View all posts by \[Author Name\]](#) | [View all posts in \[Category\]](#)

Brookfield

BROOKFIELD

Zisman Bowyer & Partners LLP
Accounting Financial

www.zbp.co.uk

SOUTH GLASGOW HOSPITALS

PROJECT

For more information about the study, please contact Dr. John P. Morrissey at (212) 305-2500 or via email at jmorrissey@nyp.edu.

TECHNICAL SERVICES

ATION LAYOUT OOR

LOCK
L CARE

Date Scale@A0
08/06/10 1:100


ATION

ATION

Name	Level	Type	Content	Sequential
G_01	PI	524	017	03


9	01	FE	524	017	00
---	----	----	-----	-----	----

<small>Notes:</small> • This drawing is copyright. • Do not make amendments from this drawing. • All discrepancies on this drawing are to be reported to the architect. • Do not modify any element of this drawing. • Use drawing only for purpose(s) issued.	
<small>Designer Identification of Hazard/Risk</small>	
SINGLE ISOLATION NSGH-01-CCW-157 Req Area:26.0m² Designed Area:26.2m²	
<small>UCM 02 14 Critical Care</small>	



1 Single bedroom: Isolation: Critical care			
Grp	ADB No	Qty	Description
3	BED016	1	BED, CCU/ITU, radio translucent rising backrest, two-way tilt, height adjustable (685-860), on castors
2	BOA1000	1	BOARD, Magnetic whiteboard, wall mounted, 900H 600W
2	CAB065	1	CABINET, drugs, self dispensing medication, lockable, wall mounted, 315H 210W 155D
1	CAL034	1	LAMP, repeat call, patient/staff or staff emergency or cardiac call
3	CHA317	2	CHAIR, upright, upholstered, stacking, wipeable
2	CLO004	1	CLOCK battery with second sweep hand, wall mounted
3	COMP1001	1	COMPUTER, complete with keyboard and screen. - 1 No. COM031 (grp 3) COMPUTER CPU - 1 No. COM033 (grp 3) COMPUTER KEYBOARD - 1 No. COM1000 (grp 3) COMPUTER MONITOR, TFT, digital flat panel display, desk top.
1	DATA1000	1	DATA POINTS, incorporating one power socket and two data/telecom points. - 1 No. OUT010 (grp 1) SOCKET outlet, switched, 13 amp, twin - 2 No. OUT131 (grp 1) SOCKET outlet double data/voice, wall/trunking mounted
2	DIS011	1	DISPENSER, barrier cream, disposable single cartridge, wall mounted
2	DIS013	1	DISPENSER, paper towel, wall mounted
2	DIS026	1	DISPENSER, Medical hand sanitizer, lever action, wall mounted
2	DIS030	1	DISPENSER, soap, disposable single cartridge, lever action, wall mounted
2	DIS438	1	DISPENSER, disposable gloves set of 4 and disposable apron, wall mounted
1	HOI006	1	HOIST PATIENT, electric, 24V, track ceiling mounted. (Length of the track to suit the individual needs.)
3	HOL004	2	HOLDER, sack, with lid foot operated, small, freestanding
3	INF002	6	INFUSION volumetric pump, 188H 110W 60D
1	LIG053	1	LUMINAIRE, examination, ceiling, adjustable, 1000 lux
3	LOC002	1	LOCKER, bedside, 3 compartment, towel rail at rear, on castors, 902H 485W 485D
3	MAT006	1	MATTRESS, ITU/CCU bed, extra care
3	MON013	1	MONITOR, vital signs, multi-parameter, with accessories, 280H 380W 215D
3	MST007	1	TROLLEY, lockable, closed, with worktop, approx 800H 660W 500D, 600mm facing
3	MST011	1	TROLLEY, large, single, with handles, 10 sets of runners, 400mm facing, buffered, braked, 1500H 600W 650D nominal
1	OUT010	1	SOCKET outlet, switched, 13 amp, twin
1	OUT054	1	CONNECTION UNIT, unswitched, 13 amp, neon indicator
1	OUT1005	1	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted
1	PAN068	1	PANEL media, for satellite dialysis machine, wall mounted, Clinical.
1	PAN1004	1	Panel, Sloped top, enclosing renal services. length as drawn.
1	PEN017	1	PENDANT DATA services, lateral and vertical movement, ceiling mounted
1	PEN1002	1	PENDANT INTENSIVE/CRITICAL CARE medical and power supply unit, 2 articulated arms, with docking system, ceiling mnt, medical gases and power outlets to HTM 08-03; pt/staff call, 14xpower, data, tele, 2xO2/H, 4xair, 2xNO, 2xNO/O, 4xO, 4xvacuum, 2xAGS, RO.
3	SPA055	1	Seat for bed/reclining chair
1	SWC028	1	SWITCH, dimmable
3	SYR003	6	SYRINGE pump, battery operated, 170H 35W 75D
3	TRN007	1	TRANSPORTER ventilator, 540H 600W 580D, (compatible with medical supply unit - PEN025)
3	TRO133	1	TROLLEY, dressing/instrument, stainless steel, buffered, 870H 750W 450D
1	TROU1000	1	TROUGH, scrub-up, hospital pattern, stainless steel, single, 800mm; HTM64.
			- 1 No. TAP892 (grp 1) TAP, bib, 2x8 mm thermostatic mixer, automatic action, sensor operated, non-touch, HTM 64 TBH6
			- 1 No. TRO801 (grp 1) TROUGH scrub-up, hospital pattern, stainless steel, single, 75mm upstand, 800W 450D, HTM64SUH1
			- 1 No. WAS102 (grp 1) WASTE, unslotted flush-grated, metal, 1. 1/2 in. HTM64WT2
			- 1 No. WAS108 (grp 1) TRAP, bottle, 1. 1/2 in, plastic resealing, HTM64TRR2/P
1	TRU1000	1	TRUNKING, Power and Data trunking, length as drawn 660 x 50 mm

02/04/2010 DRAFTED BY: [REDACTED] COMMENTS: [REDACTED]		AvB	EW
ISSUED FOR APPENDIX K FROM: [REDACTED]			
BROOKFIELD GROUP OF COMPANIES MEETINGS			
Name:	BROOKFIELD		
Date:	19/11/10		
Sign:	[REDACTED]		
Status: (A or B)	B		



Brookfield

NIGHTINGALE architects
 87-89 Newman Street
 London
 W1T 3JY
 Tel: 0207 079 9900
 Fax: 0207 079 9901
www.nightingaleassociates.com

Project


NEW SOUTH GLASGOW HOSPITALS

(NSGH) PROJECT

Drawing Title

Single bedroom: Isolation:
Critical care
B160281
TYPE 01

Job No	Drawn SLM	Checked AvB	Approved EW
09080			
DESIGN DEVELOPMENT	11/05/2010	1:50	Scd@A3
Drawing No			
Origin Zone			
Level			
Type			
Content			
Sequence			
Rev			
NA SZ XX AS 400	127-01	02	




Notes:
 There are 4 variations marked for single rooms - 3 not included
 also 2 variations for bed space D13 (560) + 560-01 + 560-02 included

Notes:
 • This drawing is copyright.
 • Do not make changes to this drawing.
 • All changes on this drawing can be reported to the architect.
 • Do not modify any element of this drawing.
 • Use drawing only for purpose(s) issued.

Designer Identification of Hazard/Risk

LOBBY
NSGH-01-CCW-092
Req Area:7.0m²
Designed Area:7.0m²

UGM | 01 | 09 Critical Care
 UGM | 02 | 14 Critical Care



Lobby to Isolation room			
Grp	ADB No	Qty	Description
1	CAL034	1	LAMP, repeat call, patient/staff or staff emergency or cardiac call
2	DIS011	1	DISPENSER, barrier cream, disposable single cartridge, wall mounted
2	DIS013	1	DISPENSER, paper towel, wall mounted
2	DIS026	1	DISPENSER, Medical hand sanitizer, lever action, wall mounted
2	DIS030	1	DISPENSER, soap, disposable single cartridge, lever action, wall mounted
2	DIS437	1	DISPENSER, disposable mask, wall mounted
2	DIS438	1	DISPENSER, disposable gloves set of 4 and disposable apron, wall mounted
3	HOL004	2	HOLDER, sack, with lid foot operated, small, freestanding
1	OUT1005	1	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted
1	SWC025	1	SWITCH, light
1	TROU1000	1	TROUGH, scrub-up, hospital pattern, stainless steel, single, 800mm; HTM64
			- 1 No. TAP892 (grp 1) TAP, bib, 2x8 mm thermostatic mixer, automatic action, sensor operated, non-touch, HTM 64 TBH8
			- 1 No. TRO801 (grp 1) TROUGH scrub-up, hospital pattern, stainless steel, single, 75mm upstand, 800W 450D. HTM64SUH1
			- 1 No. WAS102 (grp 1) WASTE, unslotted flush-grated, metal, 1. 1/2 in. HTM64WT2
			- 1 No. WAS108 (grp 1) TRAP, bottle, 1. 1/2 in, plastic resealing. HTM64TRR2/P

1 WHB1000 - 1 - WHB union code

(Full Business Case File APPENDIX K)			
Ref:	Date:	Drawn:	Revised:
		NHS PROJECT	
		NSGH BOARD	
Name:	FWnt		
Date:	19/11/10		
Sign:			
Status:	B		



Brookfield

NIGHTINGALE associates ■ ■ ■ ■
 87-91 Newman Street
 London W1T 3EY
 Tel: 0207 079 9900
 Fax: 0207 079 9901
www.nightingaleassociates.com

Project:
NEW SOUTH GLASGOW HOSPITALS (NSGH) PROJECT


Drawing Title:
LOBBY TO ISOLATION ROOM G0510B

Job No	Drawn	Checked	Approved
09080	JEP	AvB	EW
Status	DESIGN DEVELOPMENT	Date	1:50
		10/05/2010	150
Drawing No		Rev	
Origin	Zone	Level	Type
NA SZ	XX	AS 400	Sequential
			04

1:50 1 3
 0 2 4

NOTES

- FOR SYMBOLS REFER TO
ZBP DRG NO. ZBP-DRG-XX-01-000401
- THIS DRAWING TO BE READ IN CONJUNCTION
WITH ALL CONTRACT DOCUMENTATION



02 10/09/10 REVISED AS INDICATED PS
 01 04/09/10 ISSUED FOR INFORMATION RJS AP
 Rev Date Revision Notes Dim Chk

NSGH Project	
(Full Business Case) FBC APPENDIX K	
BROOKFIELD NSGH BOARD	
Name:	D. Muir P. Mair
Date:	1/1/10 24/11/10
Sign:	[Signature]
Status:	A [Signature] A
Refer to Gantt Report	
Client: [Redacted] Date: 20/07/10	
NHS	
Glasgow Caledonian University	

Contractor

Brookfield

Project: NEW SOUTH GLASGOW HOSPITALS (NSGH) PROJECT

Drawing Title: MECHANICAL SERVICES CRITICAL CARE VENTILATION SCHEMATIC (PR221 AHU's 08 - 17)

Job No: 2900 Date: APR'10 Scale@A0 NTS






Status: INFORMATION

Drawing No: Origin Zone Level Type Content Sequential Rev
Origin Zone Level Type Content Sequential Rev
ZBP XX XX SC 524 707 02

PLOTTED DATE: 01/07/10 BY: JAMES BOWYER

NOTES

1. FOR SYMBOLS REFER TO
ZBP DRG No. ZBP-XX-XX-DT-590-001
 2. THIS DRAWING TO BE READ IN CONJUNCTION
WITH ALL CONTRACT DOCUMENTATION



- NORMAL
 - FAULT - ALARM / MUTE
 - LOBBY PRESSURE DIFFERENCE
 - ROOM TEMPERATURE


INDICATIVE PRESSURE RELIEF DAMPER INFORMATION		
AIRFLOW (L/S)	PRESSURE (Pa)	INDICATIVE OVERALL SIZE WIDTH X HEIGHT (mm)
160	10	600 x 400

Y SOUTH GLASGOW HOSPITALS & LABORATORY PROJECT		Y ADULT & CHILDRENS HOSPITALS DOCUMENT REVIEW	
Representative	Date	Category	Signature
Guest	9/1/2012	A	[Redacted]
ERI		Choice Hall 10/9/12	
Action Taken Amend Subject to Amendment In Amendment and Resubmit Amend the Submitted Item and Resubmit			
Client			

Brookfield MULTIPLEX	BM	Contractor
CONTRACTOR DOCUMENT REVIEW NEW EAST GLASGOW HOSPITAL Brookfield Multiplex Received Date: <input checked="" type="checkbox"/> No Comment <input type="checkbox"/> Not subject to comments, contact and resubmit within 7 Business Days <input type="checkbox"/> Rejected – correct and resubmit within 7 Business Days		
 Greater Glas- and Cly-		

NEW SOUTH GLASGOW HOSPITALS		
FILE REF		ACTION BY
25 JUN 2012		
ACTION		
COPY TO		

(NSGH) PROJECT						
<p>Drawing Title</p> <p>MECHANICAL SERVICES</p> <p>CRITICAL CARE ISOLATION ROOMS</p> <p>VENTILATION SCHEMATIC</p> <p>(PR21) AHU's 08-17</p>						
Job No 2900		Drawn RVS		Checked AJP		Approved AP
Status CONSTRUCTION T3				Date APR '10		Scale @ A0 NTS
Drawing No.						Rev
Origin	Zone	Level	Type	Content	Sequential	
ZBP	XX	XX	SC	524	707	B

	NEW SOUTH GLASGOW HOSPITALS ADULT HOSPITAL															
		NEW SOUTH GLASGOW HOSPITALS & LABORATORY PROJECT NEW ADULT & CHILDREN'S HOSPITALS - DOCUMENT REVIEW <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">REVISION NUMBER</td> <td style="width: 25%;">REF.</td> <td style="width: 25%;">CARTOONIST</td> <td style="width: 25%;">SIGNATURE</td> </tr> <tr> <td>Z-01</td> <td>ZC</td> <td>LA 26/12/12</td> <td></td> </tr> <tr> <td colspan="4">APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE AND APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE AND APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE</td> </tr> </table>	REVISION NUMBER	REF.	CARTOONIST	SIGNATURE	Z-01	ZC	LA 26/12/12		APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE AND APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE AND APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE					
REVISION NUMBER	REF.	CARTOONIST	SIGNATURE													
Z-01	ZC	LA 26/12/12														
APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE AND APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE AND APPROVED FOR RELEASE BY THE CHIEF EXECUTIVE																
NIGHTINGALE associates ■■■■■ ROOM DATA SHEETS NSGH Critical Care Ward																
DEPARTMENT OPERATING HOURS <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th>MON</th> <th>TUE</th> <th>WED</th> <th>THURS</th> <th>FRI</th> <th>SAT</th> <th>SUN</th> </tr> <tr> <td>0000-2400</td> <td>0001-2400</td> <td>0000-2400</td> <td>0001-2400</td> <td>0100-2400</td> <td>0200-2400</td> <td>0200-2400</td> </tr> </table>			MON	TUE	WED	THURS	FRI	SAT	SUN	0000-2400	0001-2400	0000-2400	0001-2400	0100-2400	0200-2400	0200-2400
MON	TUE	WED	THURS	FRI	SAT	SUN										
0000-2400	0001-2400	0000-2400	0001-2400	0100-2400	0200-2400	0200-2400										
Status DESIGN DEVELOPMENT <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">CT Drawn By</td> <td style="width: 25%;">AvdP Checked By</td> <td style="width: 25%;">03/08/2010 DATE OF 1ST ISSUE</td> <td style="width: 25%;">12/09/2011 REVISION DATE</td> </tr> <tr> <td colspan="2">Drawing Number</td> <td colspan="2">Revision</td> </tr> <tr> <td colspan="2">NA - SZ - 01 - RD - 400 - CCW</td> <td colspan="2">04</td> </tr> </table>			CT Drawn By	AvdP Checked By	03/08/2010 DATE OF 1ST ISSUE	12/09/2011 REVISION DATE	Drawing Number		Revision		NA - SZ - 01 - RD - 400 - CCW		04			
CT Drawn By	AvdP Checked By	03/08/2010 DATE OF 1ST ISSUE	12/09/2011 REVISION DATE													
Drawing Number		Revision														
NA - SZ - 01 - RD - 400 - CCW		04														

09080

Cover Sheet

Project: 09080 Glasgow_Southern_General
 Department: NSGH CRITICAL CARE

Issue date: 12/09/11

Room Code	None	Room Name	Revision
NSGH-01-CCW-001		Riser M8	03
NSGH-01-CCW-002		Reception desk/office: 8 places	03
NSGH-01-CCW-003		Clinical equipment store 1 of 2	03
NSGH-01-CCW-004		Corridor	03
NSGH-01-CCW-005		Visitors waiting area:	03
NSGH-01-CCW-006		Bulk supplies store	03
NSGH-01-CCW-007		Clinical equipment store 2 of 2	03
NSGH-01-CCW-008		Visitors wc: Disabled/ wheelchair user	03
NSGH-01-CCW-009		Visitors wc: Disabled/ wheelchair user	03
NSGH-01-CCW-010		Visitors wc: Disabled/ wheelchair user	03
NSGH-01-CCW-011		Visitors wc: Disabled/ wheelchair user	03
NSGH-01-CCW-012		Visitors wc: Disabled/ wheelchair user	03
NSGH-01-CCW-013		Relatives wc: Disabled/ wheelchair user	03
NSGH-01-CCW-014		Relatives room	03
NSGH-01-CCW-015		Relatives room	03
NSGH-01-CCW-016		Furniture store - 1 of 3	03
NSGH-01-CCW-017		Housekeepers (cleaners) room	03
NSGH-01-CCW-018		Computer communication: IT hub room	03
NSGH-01-CCW-019		Disposal hold	03
NSGH-01-CCW-020		Patients pantry & Regeneration Area	03
NSGH-01-CCW-021		Electrical Cupboard	03
NSGH-01-CCW-022		Teaching & research office 2 places: teaching and research staff	03
NSGH-01-CCW-023		Dirty utility with urine testing	03
NSGH-01-CCW-024		Store Room - 1 of 4	03

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:11:00

Page 1 of 11

09080

Cover Sheet

Project: 09080 Glasgow_Southern_General
 Department: NSGH CRITICAL CARE

Issue date: 12/09/11

Room Code	None	Room Name	Revision
NSGH-01-CCW-025		Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-026		Patients en-suite wc & wash double assist	03
NSGH-01-CCW-027		Gowning lobby: single bedroom	03
NSGH-01-CCW-028		Staff WC	03
NSGH-01-CCW-029		Shower / WC - Assisted	03
NSGH-01-CCW-030		Clinical staff office/IT resource room: 4 places	03
NSGH-01-CCW-031		Single Room/Equivalent bed space	03
NSGH-01-CCW-032		Single Room/Equivalent bed space	03
NSGH-01-CCW-033		Single Room/Equivalent bed space	03
NSGH-01-CCW-034		Single Room/Equivalent bed space	03
NSGH-01-CCW-035		Single Room/Equivalent bed space	03
NSGH-01-CCW-036		Single Room/Equivalent bed space	03
NSGH-01-CCW-037		Corridor	03
NSGH-01-CCW-038		Cardiac arrest/emergency trolley bay	03
NSGH-01-CCW-039		Equipment Bay L	03
NSGH-01-CCW-040		Communications / Staff Base	03
NSGH-01-CCW-041		Staff Resource Room	03
NSGH-01-CCW-042	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-044	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-046	-	Riser M1	03
NSGH-01-CCW-047	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-048	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-049	-	Gowning lobby: single bedroom	03

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE	Issue date: 12/09/11	
Room Code	None	Room Name	Revision
NSGH-01-CCW-050	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-051	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-052	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-053	-	Linen Store	03
NSGH-01-CCW-054	-	Ready use medical gas cylinders store	03
NSGH-01-CCW-055	-	Clinical staff office/IT resource room: 4 places	03
NSGH-01-CCW-056	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-057	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-058	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-059	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-060	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-061	-	Electrical Cupboard	03
NSGH-01-CCW-062	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-063	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-064	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-065	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-066	[REDACTED]	Status laboratory	03
NSGH-01-CCW-067	[REDACTED]	Mobile imaging equipment bay (x-ray & Ultrasound) with image intensifiers	03
NSGH-01-CCW-068	[REDACTED]	Cardiac arrest/emergency trolley bay	03
NSGH-01-CCW-069	[REDACTED]	Corridor	03
NSGH-01-CCW-070	[REDACTED]	Equipment Bay L	03
NSGH-01-CCW-071	[REDACTED]	Communications / Staff Base	03
NSGH-01-CCW-072	[REDACTED]	Dirty utility with urine testing	03

Produced by Nightingale Associates
To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE	Issue date: 12/09/11	
Room Code	None	Room Name	Revision
NSGH-01-CCW-073	-	Shower / WC - Assisted	03
NSGH-01-CCW-074	-	Staff WC	03
NSGH-01-CCW-075	-	Clean Utility	03
NSGH-01-CCW-076	[REDACTED]	Staff Meeting / Interview	03
NSGH-01-CCW-077	[REDACTED]	Gowning lobby: single bedroom	03
NSGH-01-CCW-078	[REDACTED]	Critical care bed area; single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-079	[REDACTED]	Single Room/Equivalent bed space	03
NSGH-01-CCW-080	[REDACTED]	Ready use medical gas cylinders store	03
NSGH-01-CCW-081	[REDACTED]	Linen Store	03
NSGH-01-CCW-082	-	Clinical staff office/IT resource room: 4 places	03
NSGH-01-CCW-083	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-084	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-085	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-086	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-087	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-088	-	Electrical Cupboard	03
NSGH-01-CCW-089	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-090	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-092	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-093	-	Status laboratory	03
NSGH-01-CCW-094	-	Mobile Imaging equipment bay (x-ray & Ultrasound) with image intensifiers	03
NSGH-01-CCW-095	-	Cardiac arrest/emergency trolley bay	03
NSGH-01-CCW-096	-	Corridor	03

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE	Issue date: 12/09/11	
Room Code	None	Room Name	Revision
NSGH-01-CCW-097	-	Equipment Bay L.	03
NSGH-01-CCW-098	-	Communications / Staff Base	03
NSGH-01-CCW-099	-	Computer communication: IT hub room	03
NSGH-01-CCW-100	[REDACTED]	Clean utility	03
NSGH-01-CCW-101	-	Dirty utility with urine testing	03
NSGH-01-CCW-102	-	Staff Meeting / Interview	03
NSGH-01-CCW-103	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-104	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-105	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-106	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-107	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-108	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-109	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-110	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-111	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-112	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-113	-	Housekeepers (cleaners) room	03
NSGH-01-CCW-114	-	Store Room - 2 of 4	03
NSGH-01-CCW-115	-	Corridor	03
NSGH-01-CCW-116	-	Cardiac arrest/emergency trolley bay	03
NSGH-01-CCW-117	-	Equipment Bay L.	03
NSGH-01-CCW-118	-	Communications / Staff Base	03
NSGH-01-CCW-119	-	Staff Resource Room	03

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:11:00

Page 3 of 11

09080	Cover Sheet		
Project:	09080 Glasgow_Southern_General		
Department:	NSGH CRITICAL CARE		Issue date: 12/09/11
Room Code	None	Room Name	Revision
NSGH-01-CCW-120	-	Clean utility	03
NSGH-01-CCW-121	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-122	-	Electrical Riser RE63	03
NSGH-01-CCW-124	-	Riser M2	03
NSGH-01-CCW-126	-	Dirty Utility with urine testing/equipment cleaning	03
NSGH-01-CCW-127	-	Staff WC	03
NSGH-01-CCW-128	-	Relatives room	03
NSGH-01-CCW-129	-	Relatives room	03
NSGH-01-CCW-130	[REDACTED]	Equipment Service Room	03
NSGH-01-CCW-131	-	Pharmacy Support Area	03
NSGH-01-CCW-132	-	Blood Bank Fridge Area	03
NSGH-01-CCW-134	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-135	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-136	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-137	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-138	-	Corridor	03
NSGH-01-CCW-139	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-140	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-141	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-142	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-143	-	Disposal hold	03
NSGH-01-CCW-144	-	Furniture store - 3 of 3	03
NSGH-01-CCW-145	-	Relatives room	03

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE	Issue date: 12/09/11	
Room Code	None	Room Name	Revision
NSGH-01-CCW-146	-	Relatives room	03
NSGH-01-CCW-147	-	Store Room - 4 of 4	03
NSGH-01-CCW-148	-	Dirty Utility with urine testing	03
NSGH-01-CCW-149	-	Patients pantry & Regeneration Area	03
NSGH-01-CCW-150	[REDACTED]	Staff Resource Room	03
NSGH-01-CCW-151	-	Communications / Staff Base	03
NSGH-01-CCW-152	-	Electrical Riser RE61	03
NSGH-01-CCW-153	-	Cardiac arrest/emergency trolley bay	03
NSGH-01-CCW-154	-	Shower / WC - Assisted	03
NSGH-01-CCW-155	-	Equipment Bay L	03
NSGH-01-CCW-157	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-158	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-159	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-160	-	Riser M3	03
NSGH-01-CCW-161	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-162	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-163	-	Gowning lobby: single bedroom	03
NSGH-01-CCW-164	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-165	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-166	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-167	-	Ready use medical gas cylinders store	03
NSGH-01-CCW-167-1	-	Electrical Riser RE62	03
NSGH-01-CCW-168	-	Linen Store	03

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE	Issue date: 12/09/11	
Room Code	None	Room Name	Revision
NSGH-01-CCW-169	-	Clinical staff office/IT resource room: 4 places	03
NSGH-01-CCW-170	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-171	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-172	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-173	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-174	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-175	-	Electrical Cupboard	03
NSGH-01-CCW-176	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-177	-	Single Room/Equivalent bed space	03
NSGH-01-CCW-178	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-179	-	Patients en-suite wc & wash double assist	03
NSGH-01-CCW-180	-	Status laboratory	03
NSGH-01-CCW-181	-	Mobile imaging equipment bay (x-ray & Ultrasound) with image intensifiers	03
NSGH-01-CCW-182	-	Cardiac arrest/emergency trolley bay	03
NSGH-01-CCW-183	-	Corridor	03
NSGH-01-CCW-184	-	Equipment Bay L	03
NSGH-01-CCW-185	-	Communications / Staff Base	03
NSGH-01-CCW-186	-	Staff WC	03
NSGH-01-CCW-187	-	Shower / WC - Assisted	03
NSGH-01-CCW-188	-	Dirty utility with urine testing	03
NSGH-01-CCW-189	-	Staff Meeting / Interview	03
NSGH-01-CCW-190	-	Clean utility	03
NSGH-01-CCW-191	-	Staff WC	03

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project:	09080 Glasgow_Southern_General	Department:	NSGH CRITICAL CARE
			Issue date: 12/09/11
Room Code	None	Room Name	Revision
NSGH-01-CCW-193	-	Staff wc & wash: Ambulant user	03
NSGH-01-CCW-195	-	Staff wc & wash: Ambulant user	03
NSGH-01-CCW-196		Consultant Offices - 2 person rooms	03
NSGH-01-CCW-197		Consultant Offices - 2 person rooms	03
NSGH-01-CCW-198		Consultant Offices - 2 person rooms	03
NSGH-01-CCW-199		Riser M4	03
NSGH-01-CCW-200		Housekeepers (cleaners) room	03
NSGH-01-CCW-201		Staff Lounge (including pantry area)	03
NSGH-01-CCW-202		WC / Shower / Change - Disabled	03
NSGH-01-CCW-203		WC / Shower / Change - Disabled	03
NSGH-01-CCW-204		Corridor	03
NSGH-01-CCW-205		Female Staff changing facilities 160 places	03
NSGH-01-CCW-207		Staff wc & wash: Ambulant user	03
NSGH-01-CCW-208		Staff wc & wash: Ambulant user	03
NSGH-01-CCW-209		Staff wc & wash: Ambulant user	03
NSGH-01-CCW-210		Staff wc & wash: Ambulant user	03
NSGH-01-CCW-211		Staff shower	03
NSGH-01-CCW-212		Staff shower	03
NSGH-01-CCW-213		Staff shower	03
NSGH-01-CCW-214		Male Staff changing facilities 60 places	03
NSGH-01-CCW-215		Staff wc & wash: Ambulant user	03
NSGH-01-CCW-216		Staff wc & wash: Ambulant user	03
NSGH-01-CCW-217		Staff wc & wash: Ambulant user	03

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE	Issue date: 12/09/11	
Room Code	None	Room Name	Revision
NSGH-01-	-	Staff shower	03
CCW-218			
NSGH-01-	-	Staff shower	03
CCW-219			
NSGH-01-	-	Staff shower	03
CCW-220			
NSGH-01-	-	Furniture store - 2 of 3	03
CCW-221			
NSGH-01-	X	Seminar/training room: 40 - 45 places	03
CCW-222			
NSGH-01-		Consultant Offices - 2 person rooms	03
CCW-223			
NSGH-01-		Consultant Offices - 2 person rooms	03
CCW-224			
NSGH-01-		Staff Oncall	03
CCW-225			
NSGH-01-		Corridor	03
CCW-226			
NSGH-01-		Outreach office: 4 places	03
CCW-227			
NSGH-01-		Riser M5	03
CCW-228			
NSGH-01-		Managers office: 2 place	03
CCW-229			
NSGH-01-		Clinical directors office: 1 Manager 1 place	03
CCW-230			
NSGH-01-		Managers office: 2 place	03
CCW-231			
NSGH-01-		Consultant Offices - 2 person rooms	03
CCW-232			
NSGH-01-		Consultant Offices - 2 person rooms	03
CCW-233			
NSGH-01-		Staff WC - Ensuite to Staff Rest	03
CCW-234			
NSGH-01-		Staff wc & wash: Ambulant user	03
CCW-235			
NSGH-01-		Electrical Cupboard	03
CCW-236			
NSGH-01-		Teaching & research office 4 places: teaching and research staff	03
CCW-237			
NSGH-01-		Relatives wc: Disabled/ wheelchair user	03
CCW-238			
NSGH-01-		Critical care bed area: single room; Isolation (access via gowling lobby)	03
CCW-240			
NSGH-01-		Critical care bed area: single room; Isolation (access via gowling lobby)	03
CCW-241			
NSGH-01-			
CCW-242			

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Cover Sheet		
Project: Department:	09080 Glasgow_Southern_General NSGH CRITICAL CARE		Issue date: 12/09/11
Room Code	None	Room Name	Revision
NSGH-01-CCW-243	-	Store Room - 3 of 4	03
NSGH-01-CCW-244	-	Relatives wc: Disabled/ wheelchair user	03
NSGH-01-CCW-245	-	Critical care bed area: single room; Isolation (access via gowning lobby)	03
NSGH-01-CCW-246	-	Disposal hold	03
NSGH-01-CCW-247	-	Staff WC	03
NSGH-01-CCW-248	-	Mobile imaging equipment bay (x-ray & Ultrasound) with image intensifiers	03
NSGH-01-CCW-249	-	IPS	03
NSGH-01-CCW-250	-	IPS	03
NSGH-01-CCW-251	-	Corridor	03
NSGH-01-CCW-252	-	Corridor	03
NSGH-01-CCW-253	-	Corridor	03
NSGH-01-CCW-254	-		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:11:00

Page 11 of 11

09080	Room Data - Design Issues		Y1510B
Project:	09080 Glasgow_Southern_General	CRITICAL CARE: ICU/HDU	
Department:	01-03-02 Utility/clinical area support facilities		
Room:	Housekeepers (cleaners) room		
Room Number:	NSGH-01-CCW-017		Revision: 03
Design Criteria	<i>Briefing Room Code</i>	Y1510B	
	<i>Room Code</i>	NSGH-01-CCW-017	
	<i>Room Name</i>	Housekeepers (cleaners) room	
	<i>Room Number</i>	NSGH-01-CCW-017	
	<i>Room Instance Code</i>		
	<i>Area Required</i>	7.0 m ²	
	<i>Area Designed</i>	6.5 m ²	
Occupancy	<i>Room in use</i>	*	
Activities	<i>Personnel</i>	2 x Staff Intermittent use	
		1) Disposal of liquid waste. 2) Filling and emptying buckets. 3) Holding cleaning materials. 4) Parkin cleaning equipment. 5) Secure holding of personal belongings. 6) Use of hand-rinse basin. 7) Use of sink. 8) Use of janitorial unit.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Environmental	Y1510B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-02 Utility/clinical area support facilities	
Room:	Housekeepers (cleaners) room	
Room Number:	NSGH-01-CCW-017	Revision: 03
Temperature	<p>Winter degC 16</p> <p>Summer degC None</p> <p>Temperature Notes -</p> <p>Relative Humidity% -</p> <p>Extract ac/hr - <i>100 6</i></p> <p>Supply ac/hr -</p> <p>Mechanical Ventilation</p> <p>Notes -</p> <p>Relative Pressure NEG</p> <p>Dust Spot Efficiency 0</p> <p>Arrestance 0</p> <p>Filtration Humidity Notes 0</p>	
Ventilation		<i>extract rate?</i>
Lighting	<p>General HVAC Notes</p> <p>Service Illumination Lux 200</p> <p>Service Illumination Lux Floor</p> <p>Notes -</p> <p>Service Illumination 0</p> <p>Night Lux</p> <p>Service Illumination</p> <p>Night Lux Notes -</p> <p>Service Illumination 0</p> <p>Local Lux</p> <p>Service Illumination</p> <p>Local Lux Notes -</p> <p>Colour Rendering True</p> <p>Colour Rendering Notes Ra 85</p> <p>Standby Lighting Grade A</p> <p>Standby Lighting Grade Lighting of the level and quality equal or nearly equal to that provided by normal lighting</p> <p>Notes</p> <p>Illumination Notes - Type of control: N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 22 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 0 metres above finished floor level.</p>	
Safety	<p>Hot Surface</p> <p>Temperature deg C -</p> <p>Hot Water Temperature 60 deg C</p> <p>Safety Temperature Notes Sign required: 'Caution Very hot Water' above the sink. Hot Water Max.Temp: Washbasin 41(to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves)</p>	
General Safety Notes		

Produced by Nightingale Associates
To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	M0252B3
Project:	09080 Glasgow_Southern_General CRITICAL CARE: SHARED	
Department:	01-02-03 Office Area	
Room:	Teaching & research office 2 places; teaching and research staff	
Room Number:	NSGH-01-CCW-022	Revision: 03
Design Criteria	<i>Briefing Room Code</i>	M0252B3
	<i>Room Code</i>	NSGH-01-CCW-022
	<i>Room Name</i>	Teaching & research office 2 places; teaching and research staff
	<i>Room Number</i>	NSGH-01-CCW-022
	<i>Room Instance Code</i>	
	<i>Area Required</i>	13.0 m²
	<i>Area Designed</i>	12.0 m²
Occupancy	<i>Room in use</i>	
	<i>Personnel</i>	2 x Persons
Activities	1) Clinical administration. 2) Using computer workstation(s). 3) Using telephone(s). 4) Discussions and interviews. 5) Storing files and records. 6) Hanging coats. 7) Secure holding of personal belongings.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:13:00

Page 12 of 32

09080	Room Data - Environmental		M0252B3
Project:	09080	Glasgow_Southern_General	CRITICAL CARE; SHARED
Department:	01-02-03	Office Area	
Room:		Teaching & research office 2 places; teaching and research staff	
Room Number:	NSGH-01-CCW-022		Revision: 03
Temperature	Winter degC	21	
	Summer degC	26	
	Temperature Notes -	26oC not to be exceeded for more than 50 hours per annum against CIBSE DSY weather data; but not on successive days.	
Ventilation	Relative Humidity%	-	
	Extract ac/hr	-	
	Supply ac/hr	-	
	Mechanical Ventilation Notes -	Air volume to suit occupancy at 10 litres per second per person or cooling requirement; whichever the greater	
	Relative Pressure	BAL	
	Dust Spot Efficiency	0	
	Arrestance	0	
	Filtration Humidify Notes	0	
Lighting	General HVAC Notes		
	Service Illumination Lux	500	
	Service Illumination Lux	Desk	
	Notes -		
	Service Illumination Night Lux	0	
	Service Illumination Night Lux Notes -		
	Service Illumination Local Lux	0	
	Service Illumination Local Lux Notes -		
	Colour Rendering	True	
	Colour Rendering Notes	Ra 85	
	Standby Lighting Grade	A	
	Standby Lighting Grade Notes	Lighting of the level and quality equal or nearly equal to that provided by normal lighting	
Safety	Illumination Notes - Type of control: N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 0.85 metres above finished floor level.		
	Hot Surface	-	
	Temperature deg C		
	Hot Water Temperature deg C	-	
	Safety Temperature Notes		
General Safety Notes			

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			M0252B3			
Project:	09080 Glasgow_Southern_General CRITICAL CARE: SHARED							
Department:	01-02-03 Office Area							
Room:	Teaching & research office 2 places; teaching and research staff							
Room Number:	NSGH-01-CCW-022			Revision: 03				
New	Tr/Ex	Qty	Code	Description		Group		
2		2	BIN005	BIN, disposal, pedal, small, 360H 250 dia.		3		
1		1	BOA013	BOARD, display/notice, wall mounted, 900H 1200W		2		
1		1	BOA017	BOARD, display/notice, magnetic, wall mounted, 1200H 1200W		2		
2		2	BOA1002	BOARD, display/notice, magnetic, wall mounted, 900H 1200W		2		
1		1	CAB049	CABINET, lateral filing, 6 rails, 2 door, 1970H 1000W 470D		3		
2		2	CHA301	CHAIR, swivel, height adjustable, high back, with arms, wipeable, 5 star base, on castors		3		
2		2	CHA317	CHAIR, upright, upholstered, stacking, wipeable		3		
1		1	CLO001	CLOCK battery, wall mounted		2		
2		2	COMP1000	COMPUTER, complete with keyboard, screen and telephone. • 1 No. COM031 (grp 3) COMPUTER CPU • 1 No. COM033 (grp 3) COMPUTER KEYBOARD • 1 No. COM1000 (grp 3) COMPUTER MONITOR, TFT, digital flat panel display, desk top. • 1 No. TEL1000 (grp 3) TELEPHONE, handset, wall/desk mounted	[Union]	3		
2		2	DATA1000	DATA POINTS, incorporating two power sockets and one data/telecom point. • 2 No. OUT010 (grp 1) SOCKET outlet, switched, 13 amp, twin • 1 No. OUT131 (grp 1) SOCKET outlet double data/voice, wall/trunking mounted	[Union]	1		
2		2	DES026	DESK UNIT, cantilever, cable management, adjustable legs, modesty panel, 1400W 700D		3		
2		2	DRA056	DRAWER UNIT, 2 drawer, lockable, on castors, 600H 410W 600D		3		
4		4	HOO019	HOOK, single, small, wall mounted		2		
1		1	OUT077	OUTLET Isolator 20amp, SP&N		1		
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1		
1		1	SPA1044	SPACE, Fan Coil Unit to M&E specification		1		
1		1	SWC026	SWITCH, dimmable		1		
2		2	TRU1000	TRUNKING, Power and Data trunking, length as drawn 2 No. 1400 x 220 mm		#		

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	B1602B1
Project:	09080 Glasgow_Southern_General CRITICAL CARE; ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Critical care bed area: single room; Isolation (access via gowning lobby)	
Room Number:	NSGH-01-CCW-025.	Revision: 03
Design Criteria	<p><i>Briefing Room Code</i> B1602B1</p> <p><i>Room Code</i> NSGH-01-CCW-025</p> <p><i>Room Name</i> Critical care bed area: single room; Isolation (access via gowning lobby)</p> <p><i>Room Number</i> NSGH-01-CCW-025</p> <p><i>Room Instance Code</i></p> <p><i>Area Required</i> 26.0 m²</p> <p><i>Area Designed</i> 33.1 m²</p> <p><i>Room in use</i> -</p> <p><i>Personnel</i> 1 x Patient Up to 8 Staff</p>	
Occupancy		
Activities	1) Accommodating a patient needing continuous medical and nursing care using piped medical gases; vacuum and life-support system. 2) Medical and nursing procedures requiring all sides access to patient whilst 1-6 staff use specialised equipment. 3) Self dispensing medication or drugs. 4) Monitoring vital physiological signs. 5) Air control to provide source or protective isolation for patients at risk or liable to infect others. 6) Clinical hand washing.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:13:00

Page 23 of 32

09080

Schedule of Components by Room**B1602B1**

Project: 09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU
 Department: 01-03-01 Clinical areas
 Room: Critical care bed area: single room; Isolation (access via gowning lobby)
 Room Number: NSGH-01-CCW-025

Revision: 03

New	Tr/Ex	Qty	Code	Description	--	Group
1		1	BED016	BED, CCU/ITU, radio translucent rising backrest, two-way tilt, height adjustable (685-880), on castors		3
1		1	BOA1000	BOARD, Magnetic whiteboard, wall mounted, 900H 600W		2
1		1	CAB065	CABINET, drugs, self dispensing medication, lockable, wall mounted, 315H 210W 155D		2
2		2	CHA317	CHAIR, upright, upholstered, stacking, wipeable		3
1		1	CLO004	CLOCK battery with second sweep hand, wall mounted		2
1		1	COMP1001	COMPUTER, complete with keyboard and screen. • 1 No. COM031 (grp 3) COMPUTER CPU • 1 No. COM033 (grp 3) COMPUTER KEYBOARD • 1 No. COM1000 (grp 3) COMPUTER MONITOR, TFT, digital flat panel display, desk top.	[Union]	3
1		1	DATA1000	DATA POINTS, Incorporating two power sockets and one data/telecom point. • 2 No. OUT010 (g/p 1) SOCKET outlet, switched, 13 amp, twin • 1 No. OUT131 (grp 1) SOCKET outlet double data/voice, wall/trunking mounted	[Union]	1
1		1	DIS011	DISPENSER, barrier cream, disposable single cartridge, wall mounted		2
1		1	DIS013	DISPENSER, paper towel, wall mounted		2
1		1	DIS026	DISPENSER, Medical hand sanitizer, lever action, wall mounted		2
1		1	DIS030	DISPENSER, soap, disposable single cartridge, lever action, wall mounted		2
1		1	DIS438	DISPENSER,disposable gloves set of 4 and disposable apron, wall mounted		2
1		1	HOM1003	HOIST PATIENT, 3m straight ceiling track with motor		1
2		2	HOL004	HOLDER, sack, with lid foot operated, small, freestanding		3
6		6	INF002	INFUSION volumetric pump, 188H 110W 60D		3
1		1	LIG053	LUMINAIRE, examination, ceiling, adjustable, 1000 lux		1
1		1	LOC002	LOCKER, bedside, 3 compartment, towel rail at rear, on castors, 902H 495W 485D		3
1		1	MAT006	MATTRESS, ITU/CCU bed, extra care		3
1		1	MON013	MONITOR, vital signs, multi-parameter, with accessories, 280H 380W 215D		3

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			B1602B1			
Project:	09080 Glasgow_Southern_General CRITICAL CARE; ICU/HDU							
Department:	01-03-01 Clinical areas							
Room:	Critical care bed area; single room; Isolation (access via gowning lobby)							
Room Number:	NSGH-01-CCW-025			Revision: 03				
New	Tr/Ex	Qty	Code	Description	**	Group		
1		1	MST007	TROLLEY, computer, lockable, closed, with worktop, approx 900H 660W 500D, 800mm facing		3		
1		1	MST011	TROLLEY, large, single, with handles, 10 sets of runners, 400mm facing, buffered, braked, 1500H 600W 650D nominal		3		
1		1	OUT010	SOCKET outlet, switched, 13 amp, twin		1		
1		1	OUT054	CONNECTION UNIT, unswitched, 13 amp, neon indicator		1		
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1		
1		1	PAN069	PANEL, media, clinical, for satellite dialysis machine, wall mounted, including water osmosis point, soil stack point and mega earthling point,		1		
1		1	PAN1004	Perel, Sloped top, enclosing renal services, length as drawn.		1		
1		1	PEN017	PENDANT DATA services, lateral and vertical movement, ceiling mounted		1		
1		1	PEN10138	PENDANT INTENSIVE/CRITICAL CARE medical and power supply unit, 2 articulated arms, with docking system, ceiling mount, medical gases and power outlets to HTM 08-03; pedestal cast, 14xpower, data, telephone, 2xair, 4xO, 4xvacuum, 2xAGS		1		
1		1	SPA055	Space for bed/reclining chair		3		
1		1	SWC026	SWITCH, dimmable		1		
8		8	SYR003	SYRINGE pump, battery operated, 170H 35W 75D		3		
1		1	TRN007	TRANSPORTER ventilator, 540H 600W 580D, (compatible with medical supply unit - PEN025)		3		
1		1	TRO133	TROLLEY, dressing/instrument, stainless steel, buffered, 870H 750W 450D		3		
1		1	TROU1000	TROUGH, scrub-up, hospital pattern, stainless steel, single, 800mm; HTM64, • 1 No. OUT052 (grp 1) CONNECTION UNIT, switched, 13 amp • 1 No. TAP892 (grp 1) TAP, bib, 2x3 mm thermostatic mixer, automatic action, sensor operated, non-touch, HTM 64 TBH6 • 1 No. TRO601 (grp 1) TROUGH scrub-up, hospital pattern, stainless steel, single, 76mm upstand, 800W 400D, HTM64SUHT • 1 No. WAS102 (grp 1) WASTE, unslotted flush-grated, metal, 1.1/2 in. HTM64WT2 • 1 No. WAS108 (grp 1) TRAP, bottle, 1.1/2 in, plastic resealing, HTM64TRR2/P	(Union)	1		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			B1602B1	
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU			01-03-01 Clinical areas		
Department:	Critical care bed area: single room; Isolation (access via gowning lobby)			NSGH-01-CCW-025	Revision: 03	
New	Tr/Ex	Qty	Code	Description	--	Group
.1		1	TRU1000	TRUNKING, Power and Data trunking, length as drawn: 1 No. 1800 x 220 mm		1

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:13:00

Page 28 of 32

09080	Room Data - Design Issues	V1645B
Project:	09080 Glasgow_Southern_General CRITICAL CARE; ICU/HOU	
Department:	01-03-01 Clinical areas	
Room:	Patients en-suite wc & wash double assist	
Room Number:	NSGH-01-CCW-026	Revision: 03
Design Criteria	Briefing Room Code V1645B Room Code NSGH-01-CCW-026 Room Name Patients en-suite wc & wash double assist Room Number NSGH-01-CCW-026 Room Instance Code Area Required 4.5 m ² Area Designed 5.8 m ² Room in use -	
Occupancy		
Activities	Personnel 1 x patient 1-2 assistants Intermittent use 1) Use of assisted shower with fixed tip-up shower seat. 2) Use of assisted toilet. 3) Use of adjustable height hand-wash basin. 4) Undressing and dressing in privacy. 5) Hanging clothes. 6) Hanging towels. 7) Use of sanitary chair. 8) Use of shower chair. 9) Use of mobile hoist.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Environmental	V1645B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Patients en-suite wc & wash double assist	
Room Number:	NSGH-01-CCW-026	
	Revision: 03	
Temperature	Winter degC	22
	Summer degC	None
	Temperature Notes -	
Ventilation	Relative Humidity%	-
<i>extn exch</i>	Extract ac/hr	-
	Supply ac/hr	10
	Mechanical Ventilation	
	Notes -	
	Relative Pressure	NEG
	Dust Spot Efficiency	0
	Arrestance	0
	Filtration Humidity Notes	0
	General HVAC Notes	
Lighting	Service Illumination Lux	200
	Service Illumination Lux	Floor
	Notes -	
	Service Illumination	0
	Night Lux	
	Service Illumination	
	Night Lux Notes -	
	Service Illumination	0
	Local Lux	
	Service Illumination	
	Local Lux Notes -	
	Colour Rendering	True
	Colour Rendering Notes	Ra 85
	Standby Lighting Grade	A
	Standby Lighting Grade	Lighting of the level and quality equal or nearly equal to that provided by normal lighting
	Notes	
Safety	Illumination Notes - Type of control: N = Normal S = Selective EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 0 metres above finished floor level.	
	Hot Surface	43
	Temperature deg C	
	Hot Water Temperature deg C	41
	Safety Temperature Notes	Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves'
General Safety Notes		

Produced by Nightingale Associates
To be read with equipment dwgs. of same Rev no.

09080

Schedule of Components by Room**V1645B**

Project: 09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU
 Department: 01-03-01 Clinical areas
 Room: Patients en-suite wc & wash double assist
 Room Number: NSGH-01-CCW-026

Revision: 03

New	Tr/Ex	Qty	Code	Description	--	Group
1		1	BIN1000	SIN, sanitary towel disposal to meet HBNG0-G2 requirements.		3
3		3	CAL005	CEILING PULL CORD patient/staff call		1
1		1	CAL012	RESET UNIT, with repeat lamp, patient/staff call		1
1		1	CAL030	LAMP patient reassurance, ceiling mounted		1
1		1	DIS024	DISPENSER, soap, wall mounted		2
1		1	DIS061	DISPENSER, disposable gloves, single		2
1		1	DIS062	DISPENSER, toilet paper, dispense individual sheets		2
1		1	DIS064	DISPENSER, wipes		2
1		1	DIS067	DISPENSER, sanitary bags		2
2		2	HOO019	HOOK, single, small, wall mounted		2
1		1	LIG063	LUMINAIRE, single fluorescent lamp, wall, 8 watt, 300 mm		1
1		1	MIR002	MIRROR, wall mounted, 900H 300W		1
1		1	PIR1000	PIR Sensor, as per M&F specification		1
3		3	RAI048	RAIL, grab, vertical, wall mounted, 600mm		1
4		4	RAI161	RAIL, grab, horizontal, wall mounted, 600mm		1
2		2	RAI174	RAIL, grab, hinged, wall mounted, 650mm with toilet roll holder		1
1		1	SEA021R	SEAT, flip-up, with fold-down grab rails, adjustable height hinged with leg supports.		1
1		1	SHOW1002	SHOWER, ipsi/wall mounted. • 1 No. SHO002 (grp 1) SHOWER, slip resistant floor with drainage outlet, 900W 900D • 1 No. SHO018 (grp 1) SHOWER, valve, thermostatic mixer (associated with SHO020), HTM 64 TM1 • 1 No. SHO020 (grp 1) SHOWER, adjustable shower head hand spray (associated with SHO018), HTM 64 TM1	(Union)	1
1		1	SPA8028	1500 SQ. Wheelchair turning space		3
1		1	STF200	STORAGE UNIT, mid, shelf, 150H 300W 150D		1
1		1	TRA1002	TRACK, curtain, shower, length and shape as drawn.		1

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			V1645B			
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU							
Department:	01-03-01 Clinical areas							
Room:	Patients en-suite wc & wash double assist							
Room Number:	NSGH-01-CCW-026			Revision: 03				
New	Tr/Ex	Qty	Code	Description	-	Group		
1		1	WCAD1001	WC, adult, disabled, floor mounted. <ul style="list-style-type: none"> • 1 No. BAC002 (grp 1) BACKREST, WCtolet, padded, wall mounted • 1 No. CIS005 (grp 1) CISTERN WCtolet, concealed, reversible. To suit WC HTM64 • 1 No. WCH008 (grp 1) WCtolet pan with seat, 700 mm projection, hospital pattern, fixless pan, vitreous china, HTM64WCHO 	[Union]	1		
1		1	WHBN1003	WASH BASIN, en-suite/bathroom, with basin mounted taps. <ul style="list-style-type: none"> • 1 No. BAS106 (grp 1) BASIN, medium, general pattern, vitreous china, 1 tap right hand hole, no overflow, bottom outlet, 500W 400D, HTM64LBGM • 1 No. TAP289 (grp 1) TAP, monobloc, pillar mixer, integral thermostatic, short lever, HTM 64 TP6 • 1 No. WAS101 (grp 1) WASTE, unsloped recessed grated, metal, 1.1/4 in, with plug and chain, HTM64WT3 • 1 No. WAS107 (grp 1) TRAP, bottle, 1.1/4 in, plastic resealing, HTM64TRR1/P 	[Union]	1		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:13:00

Page 32 of 32

09080	Room Data - Design Issues	G0510B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Gowning lobby: single bedroom	
Room Number:	NSGH-01-CCW-027	Revision: 03
Design Criteria	Briefing Room Code	G0510B
	Room Code	NSGH-01-CCW-027
	Room Name	Gowning lobby: single bedroom
	Room Number	NSGH-01-CCW-027
	Room Instance Code	
	Area Required	7.0 m ²
	Area Designed	8.3 m ²
Occupancy	Room in use	-
Activities	Personnel	2 x Persons
	1) Use of clinical wash-hand basin. 2) Dispensing disposable aprons. 3) Dispensing disposable gloves. 4) Disposal of clinical waste. 5) Disposal of non-clinical waste.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:14:00

Page 1 of 33

09080	Room Data - Environmental		G0510B
Project:	09080 Glasgow_Southern_General	CRITICAL CARE: ICU/HDU	
Department:	01-03-01	Clinical areas	
Room:	Gowning lobby; single bedroom		
Room Number:	NSGH-01-CCW-027		Revision: 03
Temperature	Winter degC	21	
	Summer degC	None	
	Temperature Notes -		
Ventilation	Relative Humidity%	-	
	Extract ac/hr	-	
	Supply ac/hr	-	
	Mechanical Ventilation	See HBN 04-01 Supplement 1 for further details of specific requirements.	
	Notes -		
	Relative Pressure	POS	
	Dust Spot Efficiency	0	
	Arrestance	0	
	Filtration Humidity Notes	0	
Lighting	General HVAC Notes		
	Service Illumination Lux	200	
	Service Illumination Lux	Floor	
	Notes -		
	Service Illumination	0	
	Night Lux		
	Service Illumination		
	Night Lux Notes -		
	Service Illumination	0	
	Local Lux		
	Service Illumination		
	Local Lux Notes -		
	Colour Rendering	True	
	Colour Rendering Notes	Ra 85	
	Standby Lighting Grade	A	
	Standby Lighting Grade	Lighting of the level and quality equal or nearly equal to that provided by normal lighting	
	Notes		
Safety	Illumination Notes - Type of control: N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 22 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.6; Floors: 0.2 3. The working plane is 0 metres above finished floor level.		
	Hot Surface	43	
	Temperature deg C		
	Hot Water Temperature	41	
	deg C		
	Safety Temperature Notes	Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves'	
General Safety Notes			

Produced by Nightingale Associates
To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			G0510B			
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU							
Department:	01-03-01 Clinical areas							
Room:	Gowning lobby: single bedroom							
Room Number:	NSGH-01-CCW-027			Revision: 03				
New	Tr/Ex	Qty	Code	Description	-	Group		
1		1	CAL034	LAMP, repeat call, patient/staff or staff emergency or cardiac call		1		
1		1	DIS011	DISPENSER, barrier cream, disposable single cartridge, wall mounted		2		
1		1	DIS013	DISPENSER, paper towel, wall mounted		2		
1		1	DIS026	DISPENSER, Medical hand sanitizer, lever action, wall mounted		2		
1		1	DIS030	DISPENSER, soap, disposable single cartridge, lever action, wall mounted		2		
1		1	DIS437	DISPENSER, disposable mask, wall mounted		2		
1		1	DIS438	DISPENSER, disposable gloves set of 4 and disposable apron, wall mounted		2		
2		2	HOL004	HOLDER, sack, with lid foot operated, small, freestanding		3		
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1		
1		1	PIR1000	PIR Sensor, as per M&E specification		1		
1		1	SPA1045	SPACE, Magnetic Gauge to M&E specification		1		
1		1	WHBN1000	WASH BASIN, clinical, with non touch panel mounted tap/s.	(Union)	1		
				<ul style="list-style-type: none"> • 1 No. BA5101 (grp 1) BASIN, medium, hospital pattern, vitreous china, no tap holes, no overflow, integral back outlet, 500W x 400D, HTM64LBHM • 1 No. OUT052 (grp 1) CONNECTION UNIT, switched, 13 amp • 1 No. TAP894 (grp 1) TAP b&b, hospital pattern, integral thermostatic mixer, automatic action with sensor operation, HTM64TRHG • 1 No. WAS100 (grp 1) WASTE, unslotted flush-grated, metal, 1 1/4 in, HTM64WT1 • 1 No. WAS1000 (grp 1) TRAP, concealed waste, for back outlet basins. 				

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	B1602B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Single Room/Equivalent bed space	
Room Number:	NSGH-01-CCW-032	
	Revision: 03	
Design Criteria	<i>Briefing Room Code</i> B1602B <i>Room Code</i> NSGH-01-CCW-032 <i>Room Name</i> Single Room/Equivalent bed space <i>Room Number</i> NSGH-01-CCW-032 <i>Room Instance Code</i> <i>Area Required</i> 26.0 m ² <i>Area Designed</i> 30.1 m ² <i>Room In use</i> - <i>Personnel</i> 1 x Patient Up to 8 Staff	
Occupancy		
Activities	1) Accommodating a patient needing continuous medical and nursing care using piped medical gases; vacuum and life-support system. 2) Medical and nursing procedures requiring all sides access to patient whilst 1-6 staff use specialised equipment. 3) Self dispensing medication or drugs. 4) Monitoring vital physiological signs. 5) Air control to provide source or protective isolation for patients at risk or liable to infect others. 6) Clinical hand washing.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:14:00

Page 19 of 33

09080	Room Data - Environmental	B1602B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Single Room/Equivalent bed space	
Room Number:	NSGH-01-CCW-032	
	Revision: 03	
Temperature	Winter degC	27
	Summer degC	21
	Temperature Notes -	Summer and winter (local control) temperature control: 16 to 27 deg.C
Ventilation	Relative Humidity%	-
	Extract ac/hr	6
	Supply ac/hr	6
	Mechanical Ventilation Notes -	
	Relative Pressure	BAL
	Dust Spot Efficiency	0
	Arrestance	0
	Filtration Humidity Notes	0
Lighting	General HVAC Notes	
	Service Illumination Lux 0	
	Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.	
	Service Illumination 0	
	Night Lux	
	Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nightime - observation/night watch (lux): 20 1. Average at bedhead level. 2. Maximum point illuminance 40 lux. Nightime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.	
	Service Illumination 0	
	Local Lux	
	Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.	
	Colour Rendering True	
	Colour Rendering Notes Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K	
	Standby Lighting Grade A	
Standby Lighting Grade Notes Lighting of the level and quality equal or nearly equal to that provided by normal lighting		
Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 1 metre above finished floor level.		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Safety	<i>Hot Surface Temperature deg C</i>	43
	<i>Hot Water Temperature deg C</i>	41
	<i>Safety Temperature Notes</i>	Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves'
General Safety Notes		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:14:00

Page 21 of 33

Schedule of Components by Room					B1602B	
Project: 09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU Department: 01-03-01 Clinical areas Room: Single Room/Equivalent bed space Room Number: NSGH-01-CCW-032					Revision: 03	
New	Tr/Ex	Qty	Code	Description	--	Group
1		1	BED016	BED, CCU/ITU, radio translucent rising backrest, two-way tilt, height adjustable (605-860), on castors		3
1		1	BOA034	BOARD, marker, whiteboard, dry-wipe, with pen holder, wall mounted, 600H 900W		2
1		1	CAB065	CABINET, drugs, self dispensing medication, lockable, wall mounted, 315H 210W 155D		2
1		1	CAL1034	LAMP, repeat call, patient/staff or staff emergency or cardiac call, calling mounted		1
2		2	CHA317	CHAIR, upright, upholstered, stacking, wipeable		3
1		1	CLO004	CLOCK battery with second sweep hand, wall mounted		2
1		1	COMP1001	COMPUTER, complete with keyboard and screen. • 1 No. COM031 (grp 3) COMPUTER CPU • 1 No. COM033 (grp 3) COMPUTER KEYBOARD • 1 No. COM1000 (grp 3) COMPUTER MONITOR, TFT, digital flat panel display, desk top.	[Union]	3
1		1	DATA1000	DATA POINTS, incorporating two power sockets and one data/telecom point. • 2 No. OUT010 (grp 1) SOCKET outlet, switched, 13 amp, twin • 1 No. OUT131 (grp 1) SOCKET outlet double data/voice, wall/trunking mounted	[Union]	1
1		1	DIS011	DISPENSER, barrier cream, disposable single cartridge, wall mounted		2
1		1	DIS013	DISPENSER, paper towel, wall mounted		2
1		1	DIS026	DISPENSER, Medical hand sanitizer, lever action, wall mounted		2
1		1	DIS030	DISPENSER, soap, disposable single cartridge, lever action, wall mounted		2
1		1	DIS438	DISPENSER,disposable gloves set of 4 and disposable apron, wall mounted		2
2		2	HOL004	HOLDER, sack, with lid foot operated, small, freestanding		3
6		6	INF002	INFUSION volumetric pump, 188H 110W 60D		3
1		1	LIG053	LUMINAIRE, examination, calling, adjustable, 1000 lux		1
1		1	MAT006	MATTRESS, ITU/CCU bed, extra care		3
1		1	MON013	MONITOR, vital signs, multi-parameter, with accessories, 280H 360W 215D		3
1		1	MST005	TROLLEY, half size open frame, up to 5 sets of runners, 400mm facing, approx 850H 450W 350D		3

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			B1602B			
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU							
Department:	01-03-01 Clinical areas							
Room:	Single Room/Equivalent bed space							
Room Number:	NSGH-01-CCW-032			Revision: 03				
New	Tr/Ex	Qty	Code	Description	~	Group		
1		1	MST007	TROLLEY, computer, foldable, closed, with worktop, approx 900H 600W 300D, 600mm facing		3		
2		2	OUT010	SOCKET outlet, switched, 13 amp, twin		1		
1		1	OUT054	CONNECTION UNIT, unswitched, 13 amp, neon indicator		1		
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1		
1		1	OUT131	SOCKET outlet double data/voice, wall/trunking mounted		1		
1		1	PEN017	PENDANT DATA services, lateral and vertical movement, ceiling mounted		1		
1		1	PEN1013B	PENDANT INTENSIVE/CRITICAL CARE medical and power supply unit, 2 articulated arms, with docking system, ceiling mount, medical gases and power outlets to HTM 03-02; patient call, 1xpower, data, telephone, 2x9F, 4xO, 4xvacuum, 2xAGS		1		
1		1	SWC025	SWITCH, light		1		
8		8	SYR003	SYRINGE pump, battery operated, 170H 35W 75D		3		
2		2	TRA019	TRACK, curtain, one sided, 1200mm length		1		
1		1	TIRN007	TRANSPORTER ventilator, 540H 600W 680D, (compatible with medical supply unit - PEN025)		3		
1		1	TRO130	TROLLEY, dressing/instrument, stainless steel, antistatic castors, 870H 450W 450D		3		
1		1	TROU1000	TROUGH, scrub-up, hospital pattern, stainless steel, single, 800mm; HTM64.	(Union)	1		
				<ul style="list-style-type: none"> • 1 No. OUT052 (grp 1) CONNECTION UNIT, switched, 13 amp • 1 No. TAP892 (grp 1) TAP, bib, 2x8 mm thermostatic mixer, automatic action, sensor operated, non-touch, HTM 64 TRH6 • 1 No. TRO601 (grp 1) TROUGH scrub-up, hospital pattern, stainless steel, single, 75mm upstand, 800W 450D, HTM64SUH1 • 1 No. WAS102 (grp 1) WASTE, unslotted flush-grated, metal, 1.1/2 in. HTM64WT2 • 1 No. WAS108 (grp 1) TRAP, bottle, 1.1/2 in, plastic resealing, HTM64TRR2/P 				
2		2	TRU1000	TRUNKING, Power and Data trunking, length as drawn 1 No. 593 x 220 mm 1 No. 1533 x 220 mm		1		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	B1602B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Single Room/Equivalent bed space	
Room Number:	NSGH-01-CCW-033	
	Revision: 03	
Design Criteria	<i>Briefing Room Code</i>	B1602B
	<i>Room Code</i>	NSGH-01-CCW-033
	<i>Room Name</i>	Single Room/Equivalent bed space
	<i>Room Number</i>	NSGH-01-CCW-033
	<i>Room Instance Code</i>	
	<i>Area Required</i>	26.0 m ²
Occupancy	<i>Area Designed</i>	30.2 m ²
	<i>Room in use</i>	-
Activities	<i>Personnel</i>	1 x Patient Up to 8 Staff
	1) Accommodating a patient needing continuous medical and nursing care using piped medical gases; vacuum and life-support system. 2) Medical and nursing procedures requiring all sides access to patient whilst 1-6 staff use specialised equipment. 3) Self dispensing medication or drugs. 4) Monitoring vital physiological signs. 5) Air control to provide source or protective isolation for patients at risk or liable to infect others. 6) Clinical hand washing.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 10:14:00

Page 24 of 33

09080	Room Data - Environmental	B1602B																										
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU																											
Department:	01-03-01 Clinical areas																											
Room:	Single Room/Equivalent bed space																											
Room Number:	NSGH-01-CCW-033	Revision: 03																										
Temperature	<table border="1"> <tr><td>Winter degC</td><td>27</td></tr> <tr><td>Summer degC</td><td>21</td></tr> <tr><td>Temperature Notes -</td><td>Summer and winter (local control) temperature control: 16 to 27 deg.C</td></tr> </table>	Winter degC	27	Summer degC	21	Temperature Notes -	Summer and winter (local control) temperature control: 16 to 27 deg.C																					
Winter degC	27																											
Summer degC	21																											
Temperature Notes -	Summer and winter (local control) temperature control: 16 to 27 deg.C																											
Ventilation	<table border="1"> <tr><td>Relative Humidity%</td><td>"</td></tr> <tr><td>Extract sc/hr</td><td>6</td></tr> <tr><td>Supply sc/hr</td><td>6</td></tr> <tr><td>Mechanical Ventilation Notes -</td><td></td></tr> <tr><td>Relative Pressure</td><td>BAL</td></tr> <tr><td>Dust Spot Efficiency</td><td>0</td></tr> <tr><td>Arrestance</td><td>0</td></tr> <tr><td>Filtration Humidity Notes</td><td>0</td></tr> </table>	Relative Humidity%	"	Extract sc/hr	6	Supply sc/hr	6	Mechanical Ventilation Notes -		Relative Pressure	BAL	Dust Spot Efficiency	0	Arrestance	0	Filtration Humidity Notes	0											
Relative Humidity%	"																											
Extract sc/hr	6																											
Supply sc/hr	6																											
Mechanical Ventilation Notes -																												
Relative Pressure	BAL																											
Dust Spot Efficiency	0																											
Arrestance	0																											
Filtration Humidity Notes	0																											
Lighting	<table border="1"> <tr><td>General HVAC Notes</td><td></td></tr> <tr><td>Service Illumination Lux</td><td>0</td></tr> <tr><td>Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.</td><td></td></tr> <tr><td>Service Illumination</td><td>0</td></tr> <tr><td>Night Lux</td><td></td></tr> <tr><td>Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nightime - observation/night watch (lux): 20 1. Average a bedhead level. 2. Maximum point illuminance 40 lux. Nightime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.</td><td></td></tr> <tr><td>Service Illumination Local Lux</td><td>0</td></tr> <tr><td>Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.</td><td></td></tr> <tr><td>Colour Rendering</td><td>True</td></tr> <tr><td>Colour Rendering Notes</td><td>Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K</td></tr> <tr><td>Standby Lighting Grade</td><td>A</td></tr> <tr><td>Standby Lighting Grade Notes</td><td>Lighting of the level and quality equal or nearly equal to that provided by normal lighting</td></tr> <tr><td>Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 1 metre above finished floor level.</td><td></td></tr> </table>	General HVAC Notes		Service Illumination Lux	0	Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.		Service Illumination	0	Night Lux		Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nightime - observation/night watch (lux): 20 1. Average a bedhead level. 2. Maximum point illuminance 40 lux. Nightime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.		Service Illumination Local Lux	0	Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.		Colour Rendering	True	Colour Rendering Notes	Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K	Standby Lighting Grade	A	Standby Lighting Grade Notes	Lighting of the level and quality equal or nearly equal to that provided by normal lighting	Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 1 metre above finished floor level.		
General HVAC Notes																												
Service Illumination Lux	0																											
Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.																												
Service Illumination	0																											
Night Lux																												
Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nightime - observation/night watch (lux): 20 1. Average a bedhead level. 2. Maximum point illuminance 40 lux. Nightime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.																												
Service Illumination Local Lux	0																											
Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.																												
Colour Rendering	True																											
Colour Rendering Notes	Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K																											
Standby Lighting Grade	A																											
Standby Lighting Grade Notes	Lighting of the level and quality equal or nearly equal to that provided by normal lighting																											
Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 1 metre above finished floor level.																												

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev.no.

Safety	<i>Hot Surface Temperature deg C</i>	43
	<i>Hot Water Temperature deg C</i>	41
General Safety Notes	<i>Safety Temperature Notes</i>	Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves'

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:14:00

Page 26 of 33

09080		Schedule of Components by Room			B1602B	
Project:		09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU				
Department:		01-03-01 Clinical areas				
Room:		Single Room/Equivalent bed space				
Room Number:		NSGH-01-CCW-033			Revision: 03	
New	Tr/Ex	Qty	Code	Description	=	Group
1		1	BED016	BED, CCU/ITU, radio translucent rising backrest, two-way tilt, height adjustable (685-860), on castors		3
1		1	BOA034	BOARD, marker, whiteboard, dry-wipe, with pen holder, wall mounted, 600H 900W		2
1		1	CAB065	CABINET, drugs, self dispensing medication, lockable, wall mounted, 315H 210W 165D		2
1		1	CAL1034	LAMP, repeat call, patient/staff or staff emergency or cardiac call, ceiling mounted		1
2		2	CHA317	CHAIR, upright, upholstered, stacking, wipeable		3
1		1	CLO004	CLOCK battery with second sweep hand, wall mounted		2
1		1	COMP1001	COMPUTER, complete with keyboard and screen. • 1 No. COM031 (grp 3) COMPUTER CPU • 1 No. COM033 (grp 3) COMPUTER KEYBOARD • 1 No. COM1000 (grp 3) COMPUTER MONITOR, TFT, digital flat panel display, desk top.	[Union]	3
1		1	DATA1000	DATA POINTS, incorporating two power sockets and one data/telecom point. • 2 No. OUT010 (grp 1) SOCKET outlet, switched, 13 amp, 240V • 1 No. OUT131 (grp 1) SOCKET outlet double data/voice, wall/trunking mounted	[Union]	1
1		1	DIS011	DISPENSER, barrier cream, disposable single cartridge, wall mounted		2
1		1	DIS013	DISPENSER, paper towel, wall mounted		2
1		1	DIS026	DISPENSER, Medical hand sanitizer, lever action, wall mounted		2
1		1	DIS030	DISPENSER, soap, disposable single cartridge, lever action, wall mounted		2
1		1	DIS438	DISPENSER,disposable gloves set of 4 and disposable apron, wall mounted		2
2		2	HOL004	HOLDER, tack, with lid foot operated, small, freestanding		3
6		6	INF002	INFUSION volumetric pump, 188H 110W 60D		3
1		1	LIG063	LUMINAIRE, examination, ceiling, adjustable, 1000 lux		1
1		1	MAT006	MATTRESS, ITU/CCU bed, extra care		3
1		1	MON013	MONITOR, vital signs, multi-parameter, with accessories, 280H 360W 215D		3
1		1	MST005	TROLLEY, half size open frame, up to 6 sets of runners, 400mm facing, approx 850H 450W 350D		3

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			B1602B	
Project:		09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU				
Department:		01-03-01 Clinical areas				
Room:		Single Room/Equivalent bed space				
Room Number:		NSGH-01-CCW-033			Revision: 03	
New	Tr/Ex	Qty	Code	Description	..	Group
1		1	MST007	TROLLEY, computer, lockable, closed, with worktop, approx 900H 660W 600D, 600mm facing		3
2		2	OUT010	SOCKET outlet, switched, 13 amp, twin		1
1		1	OUT054	CONNECTION UNIT, unswitched, 13 amp, neon indicator		1
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1
1		1	OUT131	SOCKET outlet double data/voice, wall/trunking mounted		1
1		1	PEN017	PENDANT DATA services, lateral and vertical movement, ceiling mounted		1
1		1	PEN1013B	PENDANT INTENSIVE/CRITICAL CARE medical and power supply unit, 2 articulated arms, with docking system, ceiling mount, medical gases and power outlets to HTM 08-03; patient call, 14xpower, data, telephone, 2xair, 4xO, 4xvacuum, 2xAGS		1
1		1	SWC025	SWITCH, light		1
8		8	SYR003	SYRINGE pump, battery operated, 170H 35W 75D		3
1		1	TRA019	TRACK, curtain, one sided, 1200mm length		1
1		1	TRN007	TRANSPORTER ventilator, 540H 600W 680D, (compatible with medical supply unit - PEN025)		3
1		1	TRO130	TROLLEY, dressing/instrument, stainless steel, antistatic castors, 870H 450W450D		3
2		2	TRU1000	TRUNKING, Power and Data trunking, length as drawn 1 No. 593 x 220 mm 1 No. 765 x 220 mm		1
1		1	WBN1000	WASH BASIN, clinical, with non touch panel mounted taps. • 1 No. BAS101 (grp 1) BASIN, medium, hospital pattern, vitreous china, no tap holes, no overflow, integral back outlet, 500W 400D, HTM64LSHM • 1 No. OUT052 (grp 1) CONNECTION UNIT, switched, 13 amp • 1 No. TAP894 (grp 1) TAP bib, hospital pattern, integral thermostatic mixer, automatic action with sensor operation, HTM64TBH6 • 1 No. WAS100 (grp 1) WASTE, unslotted flush-graded, metal, 1.1/4 in, HTM84WT1 • 1 No. WAS1000 (grp 1) TRAP, concealed waste, for back outlet basins.	[Union]	1

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	G0510B
Project: Department: Room: Room Number:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU 01-03-01 Clinical areas Gowning lobby; single bedroom NSGH-01-CCW-049	Revision: 03

Design Criteria	<i>Briefing Room Code</i>	G0510B
	<i>Room Code</i>	NSGH-01-CCW-049
	<i>Room Name</i>	Gowning lobby; single bedroom
	<i>Room Number</i>	NSGH-01-CCW-049
	<i>Room Instance Code</i>	
Occupancy	<i>Area Required</i>	7.0 m ²
	<i>Area Designed</i>	6.4 m ²
Activities	<i>Room in use</i>	-
	<i>Personnel</i>	2 x Persons
	1) Use of clinical wash-hand basin. 2) Dispensing disposable aprons. 3) Dispensing disposable gloves. 4) Disposal of clinical waste. 5) Disposal of non-clinical waste.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Environmental	G0510B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Gowning lobby: single bedroom	
Room Number:	NSGH-01-CCW-049	Revision: 03
Temperature	Winter degC 21 Summer degC None Temperature Notes -	
Ventilation	Relative Humidity% - Extract ac/hr - Supply ac/hr - Mechanical Ventilation See HBN 04-01 Supplement 1 for further details of specific requirements. Notes - Relative Pressure POS Dust Spot Efficiency 0 Arrestance 0 Filtration Humidity Notes 0	
Lighting	General HVAC Notes Service Illumination Lux 200 Service Illumination Lux Floor Notes - Service Illumination 0 Night Lux Service Illumination Night Lux Notes - Service Illumination 0 Local Lux Service Illumination Local Lux Notes - Colour Rendering True Colour Rendering Notes Ra 85 Standby Lighting Grade A Standby Lighting Grade Lighting of the level and quality equal or nearly equal to that provided by normal lighting Notes	
Safety	Illumination Notes - Type of control: N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 22 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 0 metres above finished floor level. Hot Surface 43 Temperature deg C Hot Water Temperature 41 deg C Safety Temperature Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves Notes	
General Safety Notes		

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

Schedule of Components by Room					G0510B	
Project: Department: Room: Room Number:		09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU 01-03-01 Clinical areas Gowning lobby: single bedroom NSGH-01-CCW-049			Revision: 03	
New	Tr/Ex	Qty	Code	Description	~	Group
1		1	CAL034	LAMP, repeat call, patient/staff or staff emergency or cardiac call		1
1		1	DIS011	DISPENSER, barrier cream, disposable single cartridge, wall mounted		2
1		1	DIS013	DISPENSER, paper towel, wall mounted		2
1		1	DIS026	DISPENSER, Medical hand sanitizer, lever action, wall mounted		2
1		1	DIS030	DISPENSER, soap, disposable single cartridge, lever action, wall mounted		2
1		1	DIS437	DISPENSER, disposable mask, wall mounted		2
1		1	DIS438	DISPENSER, disposable gloves set of 4 and disposable apron, wall mounted		2
2		2	HOL004	HOLDER, sack, with lid foot operated, small, freestanding		3
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1
1		1	PIR1000	PIR Sensor, as per M&E specification		1
1		1	SPA1045	SPACE, Magnahelic Gauge to M&E specification		1
1		1	WHBN1000	WASH BASIN, clinical, with non touch panel mounted taps.	[Union]	1
				<ul style="list-style-type: none"> - 1 No. BAS101 (grp 1) BASIN, medium, hospital pattern, vitreous china, no tap holes, no overflow, integral back outlet, 600V 400D. HTM64LBHM + 1 No. OUT052 (grp 1) CONNECTION UNIT, switched, 13 amp + 1 No. TAP844 (grp 1) TAP bib, hospital pattern, integral thermostatic mixer, automatic action with sensor operation. HTM64TBHG + 1 No. WAS100 (grp 1) WASTE, unslotted flush-grated, metal, 1 1/4 in. HTM64WT1 + 1 No. WAS1000 (grp 1) TRAP, concealed waste, for back outlet basins. 		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	V1645B																		
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU																			
Department:	01-03-01 Clinical areas																			
Room:	Patients en-suite wc & wash double assist																			
Room Number:	NSGH-01-CCW-050																			
	Revision: 03																			
Design Criteria	<table border="1"> <tr><td>Briefing Room Code</td><td>V1645B</td></tr> <tr><td>Room Code</td><td>NSGH-01-CCW-050</td></tr> <tr><td>Room Name</td><td>Patients en-suite wc & wash double assist</td></tr> <tr><td>Room Number</td><td>NSGH-01-CCW-050</td></tr> <tr><td>Room Instance Code</td><td></td></tr> <tr><td>Area Required</td><td>4.5 m²</td></tr> <tr><td>Area Designed</td><td>5.4 m²</td></tr> <tr><td>Room in use</td><td>*</td></tr> <tr><td>Personnel</td><td>1 x patient 1-2 assistants Intermittent use</td></tr> </table>		Briefing Room Code	V1645B	Room Code	NSGH-01-CCW-050	Room Name	Patients en-suite wc & wash double assist	Room Number	NSGH-01-CCW-050	Room Instance Code		Area Required	4.5 m ²	Area Designed	5.4 m ²	Room in use	*	Personnel	1 x patient 1-2 assistants Intermittent use
Briefing Room Code	V1645B																			
Room Code	NSGH-01-CCW-050																			
Room Name	Patients en-suite wc & wash double assist																			
Room Number	NSGH-01-CCW-050																			
Room Instance Code																				
Area Required	4.5 m ²																			
Area Designed	5.4 m ²																			
Room in use	*																			
Personnel	1 x patient 1-2 assistants Intermittent use																			
Occupancy																				
Activities	<p>1) Use of assisted shower with fixed tip-up shower seat. 2) Use of assisted toilet. 3) Use of adjustable height hand-wash basin. 4) Undressing and dressing in privacy. 5) Hanging clothes. 6) Hanging towels. 7) Use of sanitary chair. 8) Use of shower chair. 9) Use of mobile hoist.</p>																			

Produced by Nightingale Associates
 To be read with equipment dwgs. of same Rev no.

09080	Room Data - Environmental	V1645B
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Patients en-suite wc & wash double assist	
Room Number:	NSGH-01-CCW-050	Revision: 03
Temperature	Winter degC 22 Summer degC None Temperature Notes - Relative Humidity% -	
Ventilation	Extract ac/hr 10 Supply ac/hr - Mechanical Ventilation Notes - Relative Pressure NEG Dust Spot Efficiency 0 Arrestance 0 Filtration Humidity Notes 0	
Lighting	General HVAC Notes Service Illumination Lux 200 Service Illumination Lux Floor Notes - Service Illumination 0 Night Lux Service Illumination Night Lux Notes - Service Illumination 0 Local Lux Service Illumination Local Lux Notes - Colour Rendering True Colour Rendering Notes Ra 85 Standby Lighting Grade A Standby Lighting Grade Lighting of the level and quality equal or nearly equal to that provided by normal lighting Notes	
Safety	Illumination Notes - Type of control: N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.5; Floors: 0.2 3. The working plane is 0 metres above finished floor level. Hot Surface 43 Temperature deg C Hot Water Temperature 41 deg C Safety Temperature Notes Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves'	
General Safety Notes		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			V1645B			
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU							
Department:	01-03-01 Clinical areas							
Room:	Patients en-suite wc & wash double assist							
Room Number:	NSGH-01-CCW-050			Revision: 03				
New	Tr/Ex	Qty	Code	Description	**	Group		
1		1	BIN1000	BIN, sanitary bowel disposal to meet HBN00-02 requirements.		3		
3		3	CAL005	CEILING PULL CORD patient/staff call		1		
1		1	CAL012	RESET UNIT, with repeat lamp, patient/staff call		1		
1		1	CAL030	LAMP patient reassurance, ceiling mounted		1		
1		1	DIS024	DISPENSER, soap, wall mounted		2		
1		1	DIS061	DISPENSER, disposable gloves, single		2		
1		1	DIS062	DISPENSER, toilet paper, dispense individual sheets		2		
1		1	DIS064	DISPENSER, wipes		2		
1		1	DIS067	DISPENSER, sanitary bags		2		
2		2	HOO019	HOOK, single, small, wall mounted		2		
1		1	LIG063	LUMINAIRE, single fluorescent lamp, wall, 8 watt, 300 mm		1		
1		1	MIR002	MIRROR, wall mounted, 900H 300W		1		
1		1	PIR1000	PIR Sensor, as per M&E specification		1		
3		3	RAI048	RAIL, grab, vertical, wall mounted, 600mm		1		
4		4	RAI161	RAIL, grab, horizontal, wall mounted, 600mm		1		
2		2	RAI174	RAIL, grab, hinged, wall mounted, 650mm with toilet roll holder		1		
1		1	SEA021R	SEAT, flip-up, with fold-down grab rails, adjustable right handed with leg supports.		1		
1		1	SHOW1002	SHOWER, IP54 wall mounted. • 1 No. SHO002 (grp 1) SHOWER, slip resistant floor with drainage outlet, 900W 300D • 1 No. SHO018 (grp 1) SHOWER, valve, thermostatic mixer (associated with SHO020), HTM 64 TM1 • 1 No. SHO020 (grp 1) SHOWER, adjustable shower head hand spray (associated with SHO018), HTM 64 TM1	[Union]	1		
1		1	SPA8028	1500 SQ. Wheelchair turning space		3		
1		1	STF200	STORAGE UNIT, mid, shelf, 150H 300W 150D		1		
1		1	TRA1002	TRACK, curtain, shower, length and shape as drawn.		1		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			V1645B	
Project:		09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU				
Department:		01-03-01 Clinical areas				
Room:		Patients en-suite wc & wash double assist				
Room Number:		NSGH-01-CCW-050			Revision: 03	
New	Tr/Ex	Qty	Code	Description	-	Group
1		1	WCAD1001	WC, adult, disabled, floor mounted. • 1 No. BAC002 (grp 1) BACKREST, WC/toilet, padded, wall mounted • 1 No. CIS006 (grp 1) CISTERN WC/toilet, concealed, reversible, To suit WC HTM64 • 1 No. WCH005 (grp 1) WC/toilet pan with seal, 700 mm projection, hospital pattern, rimless pan, vitreous china, HTM64WC0D	{Union}	1
1		1	WHBN1003	WASH BASIN, en-suite/bathroom, with basin mounted taps. • 1 No. BAS106 (grp 1) BASIN, medium, general pattern, vitreous china, 1 tap right hand hole, no overflow, bottom outlet, 500Wx400D. HTM64.BGM • 1 No. TAP289 (grp 1) TAP, monobloc, pillar mixer, integral thermostatic, short lever, HTM 64 TP6 • 1 No. WAS101 (grp 1) WASTE, unsloshed recessed grated, metal, 1 1/4 in. with plug and chain. HTM64WT3 • 1 No. WAS107 (grp 1) TRAP, bottle, 1 1/4 in, plastic resealing, HTM64TRR1/P	{Union}	1

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080	Room Data - Design Issues	B1602B1
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU	
Department:	01-03-01 Clinical areas	
Room:	Critical care bed area: single room; Isolation (access via gowning lobby)	
Room Number:	NSGH-01-CCW-051	Revision: 03
Design Criteria	<p><i>Briefing Room Code</i> B1602B1</p> <p><i>Room Code</i> NSGH-01-CCW-051</p> <p><i>Room Name</i> Critical care bed area: single room; Isolation (access via gowning lobby)</p> <p><i>Room Number</i> NSGH-01-CCW-051</p> <p><i>Room Instance Code</i></p> <p><i>Area Required</i> 26.0 m²</p> <p><i>Area Designed</i> 25.9 m²</p>	
Occupancy	<i>Room in use</i> -	
Activities	<i>Personnel</i> 1 x Patient Up to 8 Staff 1) Accommodating a patient needing continuous medical and nursing care using piped medical gases; vacuum and life-support system. 2) Medical and nursing procedures requiring all sides access to patient whilst 1-6 staff use specialised equipment. 3) Self dispensing medication or drugs. 4) Monitoring vital physiological signs. 5) Air control to provide source or protective isolation for patients at risk or liable to infect others. 6) Clinical hand washing.	

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:10:00

Page 21 of 31

09080	Room Data - Environmental	B1602B1																								
Project:	09080 Glasgow_Southern_General CRITICAL CARE; ICU/HDU																									
Department:	01-03-01 Clinical areas																									
Room:	Critical care bed area: single room; Isolation (access via gowning lobby)																									
Room Number:	NSGH-01-CCW-051	Revision: 03																								
Temperature	<table border="1"> <tr><td>Winter degC</td><td>27</td></tr> <tr><td>Summer degC</td><td>21</td></tr> <tr><td>Temperature Notes -</td><td>Summer and winter (local control) temperature control: 16 to 27 deg.C</td></tr> </table>	Winter degC	27	Summer degC	21	Temperature Notes -	Summer and winter (local control) temperature control: 16 to 27 deg.C																			
Winter degC	27																									
Summer degC	21																									
Temperature Notes -	Summer and winter (local control) temperature control: 16 to 27 deg.C																									
Ventilation	<table border="1"> <tr><td>Relative Humidity%</td><td>-</td></tr> <tr><td>Extract ac/hr</td><td>-</td></tr> <tr><td>Supply ac/hr</td><td>-</td></tr> <tr><td>Mechanical Ventilation Notes -</td><td>See Table 1 of HBN 04-01 Supplement 1 for guide to air volumes and pressure differentials.</td></tr> <tr><td>Relative Pressure</td><td>-</td></tr> <tr><td>Dust Spot Efficiency</td><td>0</td></tr> <tr><td>Arrestance</td><td>0</td></tr> <tr><td>Filtration Humidity Notes</td><td>0</td></tr> </table>	Relative Humidity%	-	Extract ac/hr	-	Supply ac/hr	-	Mechanical Ventilation Notes -	See Table 1 of HBN 04-01 Supplement 1 for guide to air volumes and pressure differentials.	Relative Pressure	-	Dust Spot Efficiency	0	Arrestance	0	Filtration Humidity Notes	0									
Relative Humidity%	-																									
Extract ac/hr	-																									
Supply ac/hr	-																									
Mechanical Ventilation Notes -	See Table 1 of HBN 04-01 Supplement 1 for guide to air volumes and pressure differentials.																									
Relative Pressure	-																									
Dust Spot Efficiency	0																									
Arrestance	0																									
Filtration Humidity Notes	0																									
Lighting	<table border="1"> <tr><td>General HVAC Notes</td><td></td></tr> <tr><td>Service Illumination Lux</td><td>0</td></tr> <tr><td>Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.</td><td></td></tr> <tr><td>Service Illumination Night Lux</td><td>0</td></tr> <tr><td>Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nighttime - observation/night watch (lux): 20 1. Average at bedhead level. 2. Maximum point illuminance 40 lux. Nighttime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.</td><td></td></tr> <tr><td>Service Illumination Local Lux</td><td>0</td></tr> <tr><td>Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.</td><td></td></tr> <tr><td>Colour Rendering</td><td>True</td></tr> <tr><td>Colour Rendering Notes</td><td>Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K</td></tr> <tr><td>Standby Lighting Grade</td><td>A</td></tr> <tr><td>Standby Lighting Grade Notes</td><td>Lighting of the level and quality equal or nearly equal to that provided by normal lighting</td></tr> <tr><td>Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.6; Floors: 0.2 3. The working plane is 1 metre above finished floor level.</td><td></td></tr> </table>	General HVAC Notes		Service Illumination Lux	0	Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.		Service Illumination Night Lux	0	Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nighttime - observation/night watch (lux): 20 1. Average at bedhead level. 2. Maximum point illuminance 40 lux. Nighttime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.		Service Illumination Local Lux	0	Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.		Colour Rendering	True	Colour Rendering Notes	Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K	Standby Lighting Grade	A	Standby Lighting Grade Notes	Lighting of the level and quality equal or nearly equal to that provided by normal lighting	Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.6; Floors: 0.2 3. The working plane is 1 metre above finished floor level.		
General HVAC Notes																										
Service Illumination Lux	0																									
Service Illumination Lux Notes - Daytime - general (lux): 100 1. Average at floor level of circulation space. 2. Maximum point illuminance 170 lux. Daytime - bedhead (lux): 30 to 50 1. Average at bedhead. Daytime - bed (lux): 300 1. Average over bed area for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux.																										
Service Illumination Night Lux	0																									
Service Illumination Night Lux Notes - Nightime - general (lux): 5 1. Average at floor level of circulation space. Nighttime - observation/night watch (lux): 20 1. Average at bedhead level. 2. Maximum point illuminance 40 lux. Nighttime - night light (lux): 5 to 10. 1. Average at bedhead level. 2. Maximum point illuminance 10 lux.																										
Service Illumination Local Lux	0																									
Service Illumination Local Lux Notes - Local task illumination (lux): 300 1. Average at bedhead for simple observation/examination purposes. 2. Maximum point illuminance 520 Lux. 3. Average of 1000 Lux at bedhead where examination or treatment is to be carried out.																										
Colour Rendering	True																									
Colour Rendering Notes	Not applicable to night lighting. General lighting - Colour rendering characteristics (Ra): 85 Examination lighting - Colour rendering characteristics (Ra): 90 Minimum colour appearance of 4000K																									
Standby Lighting Grade	A																									
Standby Lighting Grade Notes	Lighting of the level and quality equal or nearly equal to that provided by normal lighting																									
Illumination Notes - Type of control: S/N N = Normal S = Selective V = Variable EM = Energy Management System Unified glare rating limit (UGRL): 19 Areas in which VDT present to comply with CIBSE Lighting Guide LG3 "The Visual Environment for Display Screen Use" Addendum 2001 Y = Dedicated emergency lighting required in compliance with BS 5266. General lighting notes: 1. Healthcare environment lighting installations to comply with CIBSE Lighting Guides LG2; LG3; & LG7 as applicable. 2. Default values to be used where surface reflectance factors not known: Ceilings: 0.7 ; Walls: 0.6; Floors: 0.2 3. The working plane is 1 metre above finished floor level.																										

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

Safety	<i>Hot Surface Temperature deg C</i>	43
	<i>Hot Water Temperature deg C</i>	41
	<i>Safety Temperature Notes</i>	Maximum hot water temperature to be achieved in compliance with SHTN 6 'The Safe Operation and Maintenance of Thermostatic Mixing Valves'
General Safety Notes		

Produced by Nightingale Associates
To be read with equipment dwgs. of same Rev no.

Last Saved: 12/09/2011 13:16:00

Page 23 of 31

09080		Schedule of Components by Room			B1602B1			
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU							
Department:	01-03-01 Clinical areas							
Room:	Critical care bed area; single room; isolation (access via gowning lobby)							
Room Number:	NSGH-01-CCW-051			Revision: 03				
New	Tr/Ex	Qty	Code	Description	--	Group		
1		1	BED016	BED, CCU/TU, radio translucent rising backrest, two-way tilt, height adjustable (685-860), on castors		3		
1		1	BOA1000	BOARD, Magnetic whiteboard, wall mounted, 900H 600W		2		
1		1	CAB065	CABINET, drugs, self dispensing medication, lockable, wall mounted, 316H 210W 160D		2		
2		2	CHA317	CHAIR, upright, upholstered, stacking, wipeable		3		
1		1	CLO004	CLOCK battery with second sweep hand, wall mounted		2		
1		1	COMP1001	COMPUTER, complete with keyboard and screen. • 1 No. COM031 (grp 3) COMPUTER CPU • 1 No. COM033 (grp 3) COMPUTER KEYBOARD • 1 No. COM1000 (grp 3) COMPUTER MONITOR, TFT, digital flat panel display, desk top.	(Union)	3		
1		1	DATA1000	DATA POINTS, incorporating two power sockets and one data/telecom point. • 2 No. OUT010 (grp 1) SOCKET outlet, switched, 13 amp, fusa • 1 No. OUT131 (grp 1) SOCKET outlet double data/voice, wall/trunking mounted	(Union)	1		
1		1	DIS011	DISPENSER, barrier cream, disposable single cartridge, wall mounted		2		
1		1	DIS013	DISPENSER, paper towel, wall mounted		2		
1		1	DIS026	DISPENSER, Medical hand sanitizer, lever action, wall mounted		2		
1		1	DIS030	DISPENSER, soap, disposable single cartridge, lever action, wall mounted		2		
1		1	DIS438	DISPENSER, disposable gloves set of 4 and disposable apron, wall mounted		2		
1		1	HOL1003	HOIST PATIENT, 3m straight ceiling track with motor		1		
2		2	HOL004	HOLDER, sack, with lid foot operated, small, freestanding		3		
6		6	INF002	INFUSION volumetric pump, 188H 110W 60D		3		
1		1	LIG053	LUMINAIRE, examination, ceiling, adjustable, 1000 lux		1		
1		1	LOC002	LOCKER, bedside, 3 compartment, towel rail at rear, on castors, 802H 485W 485D		3		
1		1	MAT006	MATTRESS, ITU/CCU bed, extra care		3		
1		1	MON013	MONITOR, vital signs, multi-parameter, with accessories, 280H 360W 216D		3		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			B1602B1	
Project:		09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU				
Department:		01-03-01 Clinical areas				
Room:		Critical care bed area: single room; Isolation (access via gowning lobby)				
Room Number:		NSGH-01-CCW-051			Revision: 03	
New	Tr/Ex	Qty	Code	Description	--	Group
1		1	MST007	TROLLEY, computer, lockable, closed, with worktop, approx 900H 660W 500D, 600mm facing		3
1		1	MST011	TROLLEY, large, single, with handles, 10 sets of runners, 400mm facing, buffered, braked, 1500H 600W 650D nominal		3
1		1	OUT010	SOCKET outlet, switched, 13 amp, twin		1
1		1	OUT054	CONNECTION UNIT, unswitched, 13 amp, neon indicator		1
1		1	OUT1005	CLEANERS SOCKET outlet, switched, 13 amp, single, wall mounted		1
1		1	PAN059	PANEL media, clinical, for satellite dialysis machine, wall mounted, including water osmosis point, soil slack point and megan earthing point.		1
1		1	PAN1004	Panel, Sloped top, enclosing renal services, length as drawn.		1
1		1	PEN017	PENDANT DATA services, lateral and vertical movement, ceiling mounted		1
1		1	PEN1013B	PENDANT INTENSIVE/CRITICAL CARE medical and power supply unit, 2 articulated arms, with docking system, ceiling mount, medical gases and power outlets to HTM 08-03; patient call, 14xpower, data, telephone, 2xair, 4xO, 4xvacuum, 2xAGS		1
1		1	SPA055	Space for bedridden chair		3
1		1	SWC026	SWITCH, dimmable		1
8		8	SYR003	SYRINGE pump, battery operated, 170H 35W 75D		3
1		1	TRN007	TRANSPORTER ventilator, 540H 600W 580D, (compatible with medical supply unit - PEN025)		3
1		1	TRO133	TROLLEY, dressing/instrument, stainless steel, buffered, 870W 750W 450D		3
1		1	TROU1000	TROUGH, scrub-up, hospital pattern, stainless steel, single, 800mm; HTM64	[Union]	1
				- 1 No. OUT082 (grp 1) CONNECTION UNIT, switched, 13 amp + 1 No. TAP892 (grp 1) TAP, bib, 2x8 mm thermostatic mixer, automatic action, sensor operated, non-touch, HTM 64 TBHS + 1 No. TRO601 (grp 1) TROUGH scrub-up, hospital pattern, stainless steel, single, 75mm upstand, 800W 450D; HTM64SUH1 + 1 No. WAS102 (grp 1) WASTE, unslotted flush-grated, metal, 1.1/2 in; HTM64WT2 + 1 No. WAS108 (grp 1) TRAP, bottle, 1.1/2 in, plastic resealing, HTM64TRR2/P		

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.

09080		Schedule of Components by Room			B1602B1	
Project:	09080 Glasgow_Southern_General CRITICAL CARE: ICU/HDU			01-03-01 Clinical areas		
Department:	Critical care bed area; single room; Isolation (access via gowning lobby)			NSGH-01-CCW-051	Revision: 03	
New	Tr/Ex	Qty	Code	Description		Group
1		1	TRU1000	TRUNKING, Power and Data Trunking, length as drawn 1 No. 650 x 220 mm		1

Produced by Nightingale Associates

To be read with equipment dwgs. of same Rev no.



SCOTTISH HOSPITALS INQUIRY

**Bundle of documents for Oral hearings commencing from 19 August 2024 in
relation to the Queen Elizabeth University Hospital and the Royal Hospital for
Children, Glasgow**

Bundle 47 – Volume 8

Critical Care – Drawings and Room Data Sheets